



# **A40**

# **OWNERS MANUAL**

**Manual No. 407900000**

Rev. 9/2/2003

**Serial No.** \_\_\_\_\_

**Mailing Address:**

**P.O. Box 580697**

**Tulsa, OK 74158-0697**

**Physical Address:**

**4707 N. Mingo Rd.**

**Tulsa, OK 74117-5904**

**Phone (918) 836-0463**

**Fax (918) 834-5979**

**<http://www.autocrane.com>**





## Auto Crane Warranty Registration

Fax Transmission

To: Warranty Department Fax: (918) 834-5979  
From: \_\_\_\_\_ Date: \_\_\_\_\_  
Re: Product Registration Pages: \_\_\_\_\_

**End User Information:** (Required for Warranty Activation)

Name: \_\_\_\_\_ Phone: \_\_\_\_\_  
Address: \_\_\_\_\_  
City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_  
Contact: \_\_\_\_\_ E-mail Address: \_\_\_\_\_

**Distributor Information:** (Required for Warranty Activation)

Name: \_\_\_\_\_  
Address: \_\_\_\_\_  
City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_  
Contact: \_\_\_\_\_ E-mail Address: \_\_\_\_\_

**Product Information:** (Required for Warranty Activation)

Model No.: \_\_\_\_\_ Serial No.: \_\_\_\_\_  
Date Product Delivered: \_\_\_\_\_ Date Processed:\* \_\_\_\_\_  
VIN # \_\_\_\_\_ \* For Auto Crane use only

### ONE REGISTRATION FORM PER UNIT (CRANE OR BODY)

Registration form must be mailed or faxed within 15 days of customer installation.

Mail to:  
Warranty Department  
Auto Crane Company  
P.O. Box 581510  
Tulsa, OK 74158-0697





***A40 ARTICULATING CRANE  
OWNER'S MANUAL – REVISION RECORD***

| <b>Revision<br/>Date</b> | <b>Section(s)<br/>Or<br/>Page(s)</b> | <b>Description of Change</b>                                 |
|--------------------------|--------------------------------------|--------------------------------------------------------------|
| 09/02/03                 | Last page                            | New 2-year warranty policy to replace 1-year warranty policy |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |
|                          |                                      |                                                              |





# ***WARNINGS***

**WARNING!** Federal law (49 cfr part 571) requires that the Final Stage Manufacturer of a vehicle certify that the vehicle complies with all applicable federal regulations. Any modifications performed on the vehicle prior to the final state are also considered intermediate stage manufacturing and must be certified as to compliance. The installer of this crane and body is considered on of the manufacturers of the vehicle. As such a manufacturer, the installer is responsible for compliance with all applicable federal and state regulations, and is required to certify that the vehicle is in compliance.

**WARNING!** It is the further responsibility of the installer to comply with the OSHA Truck Crane Stability Requirements as specified by 29 CFR part 1910.180 (C) (1).

**WARNING! NEVER OPERATE THE CRANE NEAR ELECTRICAL POWER LINES!**

**Death** or serious injury will result from boom, line, or load contacting electric lines. Do not use crane within 10 feet (3.05m) of electric power lines carrying up to 50,000 volts. One foot additional clearance is required for every additional 30,000 volts or less. **SEE DANGER DECAL (P/N 040529)** in this Owner's Manual.

**WARNING! NEVER.....**

- ◆ **EXCEED** load chart capacities (centerline of rotation to hoist hook).
- ◆ Un-reel last 5 wraps of cable from drum!
- ◆ Wrap cable around load!
- ◆ Attempt to lift or drag a load from the side! The boom can fail far below its rated capacity.
- ◆ Weld, modify, or use unauthorized components on any Auto Crane unit! This will void any warranty or liability. Also failure of the crane may result.
- ◆ Place a chain link on the tip of the hook and try to lift a load!
- ◆ Use a sling bar or anything larger than the hook throat that could prevent the hook latch from closing, thus negating the safety feature!
- ◆ Hold on any pendant Select Switch that will cause unsafe operating conditions!

**WARNING!** In using a hook with latch, **ALWAYS** make sure that the hook throat is closed before lifting a load! Proper attention and common sense applied to the use of the hoist hook and various slings will prevent possible damage to material being hoisted and may prevent injury to personnel.

**WARNING!** Failure to correctly plumb and wire crane can cause inadvertent operation and damage to crane and/or personnel!

**WARNING!** Auto Crane Company remote controlled cranes are not designed or intended to be used for any applications involving the lifting or moving of personnel.

**WARNING! ALWAYS** operate the crane in compliance with the load capacity chart. **DO NOT USE** the overload shutdown device to determine maximum rated loads, if the crane is equipped with this type of device.

## **READ THIS PAGE**





## ***A40 OWNER'S MANUAL TABLE OF CONTENTS***

|                                             | PAGE      |
|---------------------------------------------|-----------|
| 1 INTRODUCTION .....                        | 1-1.0.0   |
| 2 GENERAL DESCRIPTION .....                 | 2-1.0.0   |
| 3 GENERAL SPECIFICATIONS & DIMENSIONS ..... | 3-1.0.0   |
| 4 LOAD CHART .....                          | 4-1.0.0   |
| 5 SAFETY TIPS AND PRECAUTIONS .....         | 5-1.0.0   |
| 6 MOUNTING & INSTALLATION .....             | 6-1.0.0   |
| 7 OPERATION OF UNIT .....                   | 7-1.0.0   |
| 8 INSPECTION, TESTING & MAINTENANCE .....   | 8-1.0.0   |
| 9 MECHANICAL SECTION .....                  | 9-1.0.0   |
| 10 HYDRAULIC SECTION .....                  | 10-1.0.0  |
| 11 DECAL LAYOUT .....                       | 11-1.0.0  |
| 11 SAFETY DECAL .....                       | 11-5.0.0  |
| 12 TROUBLESHOOTING .....                    | 12-1.0.0  |
| 13 OPTIONS .....                            | 13-1.0.0  |
| 14 WARRANTY .....                           | Last Page |



***NOTES***



## ***A40 INTRODUCTION***

Auto Crane products are designed to provide many years of safe, trouble-free, dependable service when properly used and maintained.

To assist you in obtaining the best service from your crane and to avoid untimely crane and/or vehicle failure, this manual provides the following operating and service instructions. It is **specifically recommended** that all operating and service personnel consider this manual as mandatory material for reading and study before operating or servicing Auto crane products. It is **highly recommended** that crane owners, equipment managers and supervisors also read this manual.

Auto Crane has incorporated several safety features in the A-40 series cranes for your protection. The choice of materials and the design of the electrical system minimizes weight and lengthens durability. Holding valves prevent the load from dropping if a hose should fail. A **10 micron filter** in the return line of the hydraulic system removes dirt and grit that may cause erratic operation. The reservoir has a **15 micron air filter** in the filler cap. The pump has a **100 mesh strainer** in the suction line.

For your convenience the overall dimensions of the A40 crane are on the General Dimension Drawing, Section 3.

Remember, the crane adds weight to the vehicle. Adding weight may change the driving and riding characteristics of the vehicle unless the appropriate overload spring(s) are installed on the truck. The payload of the vehicle is reduced by the weight of the crane. The operator should exercise care when loading the vehicle. Distributing the payload on the vehicle evenly will greatly improve the driving and riding characteristics of the vehicle. **A minimum G.V.W. of 17,500 lbs. and a minimum RBM of 600,000 is recommended for mounting the A40 series cranes.**

---

**Auto Crane Company issues a limited warranty certificate with each unit sold. See last page for warranty policy.**

---

It has always been Auto Crane Company policy to handle all warranty claims we receive as promptly as possible. If a warranty claim involves discrepant material or workmanship, Auto Crane will take immediate corrective action. It is understandable that Auto Crane company cannot

assume responsibility of liability when it is obvious that our products have been abused, mis-used, overloaded or otherwise damaged by inexperienced persons trying to operate the equipment without reading the manual.

**Auto Crane will not assume responsibility or liability for any modifications or changes made to a unit, or installation of component parts done without authorization.**

### **DISTRIBUTOR ASSISTANCE:**

Should you require any assistance not given in this manual, we recommend that you consult your nearest Auto Crane Distributor. Our distributors sell authorized parts and have service departments that can solve almost any needed repair.

Auto Crane maintains distributor network and a knowledgeable Customer Service Department. In most cases, an equipment problem is solved via phone conversation with your distributor. When the distributor can not handle the problem, our customer service department can assist and can bring a regional sales manager or a factory serviceman into the solution.

Auto Crane Company's extensive Research and Development Program allow our customers to use the best equipment on the market. Our Engineering Staff and our knowledgeable sales people, are always available to our customers in solving crane and winch-type application problems. When in doubt, call the Auto Crane factory.

This manual does not cover all maintenance, operating, or repair instructions pertinent to all possible situations. If you require additional information, please contact the **Auto Crane Co.** at the following telephone number: **(918) 836-0463**.

The information contained in the manual is in effect at the time of this printing. Auto Crane Company reserves the right to update this material without notice or obligation.

**NOTE: THIS MANUAL SHOULD REMAIN WITH THE CRANE AT ALL TIMES.**



## ***A40 GENERAL DESCRIPTION***

The Auto Crane A40 knuckle boom is an all hydraulic crane with a 40,000 ft-lb rating. It is suitable for both hook and attachment service.

The A40 comes in (4) basic configurations:

1. (1) Hydraulic Extension with a horizontal reach of 17 ft. -10 in.
2. (1) Hydraulic Extension & (1) Manual Extension with a horizontal reach of 23 ft. -7 in.
3. (2) Hydraulic Extension with a horizontal reach of 23 ft. -7 in.
4. (2) Hydraulic Extension & (1) Manual Extension with a horizontal reach of 29 ft. -4 in.

The main components of the crane are:

1. Outriggers
2. Crane Base Assembly
3. Rotation System
4. Control Valve
5. Pedestal Assembly
6. Inner Boom
7. Lift Cylinder
8. Outer Boom
9. Outer Boom Cylinder
10. Telescoping Boom Section(s) and Extension Cylinder
11. Manual Boom
12. Reservoir

### **OUTRIGGERS**

The outriggers are extended manually in the horizontal direction and are raised and lowered hydraulically. Optional hydraulic in & out is available. Outriggers are operated by selecting the option at the main control valve, manually moving the Outrigger Slide and raising or lowering the foot with the manual control valve on each Outrigger Cylinder. Outrigger cylinders have integral dual pilot operated check valves which will close if a hose break occurs, preventing any uncontrolled movement of outrigger cylinder and to prevent an outrigger cylinder from drifting down once they have been stowed. Outrigger span is 12 ft. when extended. Once the outrigger slides are extended or retracted to their

maximum or minimum span they are locked by a spring loaded hand operated catch. The Outriggers should always be extended to their maximum out position before operating crane.

### **CRANE BASE ASSEMBLY**

The crane base is an all welded structure which consists of mounting brackets to mount crane to truck frame, outrigger cross tube, base plate to mount rotation bearing, mounting plate for hydraulic control valve and handles.

### **ROTATION SYSTEM**

Rotation system consists of a integral ball rotation bearing and worm drive powered by a hydraulic rotation motor. The rotation motor is mounted directly to the worm shaft. Crane has approximately 390 degrees of rotation. The zero centerline of rotation of the crane is at the longitudinal centerline of truck frame facing forward if mounted behind cab. All components of the rotation system are serviceable without removal of base assembly from truck frame. Crane rotation output 5400 ft-lbs of torque.

### **CONTROL VALVE**

(5) section manual control valves standard with remote actuators on the opposite side of crane base. Optional (7) section valve, (2) auxiliary functions is available. The first section is to select or deselect to Outriggers. If the outriggers a on the other crane functions are off and vise-a-verse. The remaining (4) sections are to control the crane functions. Control valve has adjustable inlet relief valve set at 3500 psi. Each section has one or two port relief's to limit the capacity per function. This prevents Overloading the any crane function. Please refer to the Hydraulic Schematic in this manual for specific settings.



## ***A40 GENERAL DESCRIPTION***

### **PEDESTAL ASSEMBLY**

The pedestal assembly is an all welded structure consisting of a base plate used to mount two vertical columns which the inner boom is hinged to and the outer boom swings along side.

### **BOOM**

Inner boom assembly is an all welded structure consisting of an inner boom pivot which is hinged to the pedestal, outer boom pivot and a common pivot for the inner and outer boom cylinders.

### **INNER LIFT CYLINDER**

The inner boom is actuated by a single double acting lift cylinder with a single counter-balance cartridge mounted in a block directly to the cylinder. Both ends of the cylinder have 2 in. replaceable self-lubricating bushing

### **OUTER BOOM & OUTER BOOM CYLINDER**

Outer boom assembly is an all welded structure which is hinged to one end of the inner boom assembly and is actuated by an Outer Boom Cylinder. Outer boom houses the extension section(s) which are moved by a one or two extension cylinders. The outer boom which is offset to clear the pedestal includes a knuckle assembly which is hinged to the inner boom assembly. .

### **TELESCOPING BOOM SECTION(S) & EXTENSION CYLINDER**

One or two hydraulic telescoping boom sections are inserted one inside another and then into outer boom assembly. Telescoping boom sections are actuated by one or two extension cylinders with 64 in of stroke each.

### **MANUAL BOOM (OPTIONAL)**

The manual boom is a one piece boom section which is installed into the last hydraulic telescoping boom extension. It is pinned into place for both storage and extension.

### **RESERVOIR**

Reservoir capacity is 12 gallons with 100 mesh suction strainer mounted in reservoir, sight level indicators with temperature, a baffle to reduce oil splash and a in-tank 10 micro filter that is a filler and breather combined.



## ***A40 GENERAL SPECIFICATIONS***

### **Dimensions**

**Width:** 21.5 in

**Height:** 68 in from top of chassis rails

**Length:** 96 in Outriggers stored  
144 in Outriggers extended

**Weight:** 1750 lbs Std Crane  
1860 lbs (1) Manual Ext  
2040 lbs (2) Hydraulic Ext  
2120 lbs (2) Hyd Ext,  
(1) Man Ext

Mounting Space: 24 in min

### **Center of Gravity**

Horizontal: Centerline of chassis  
Vertical: 18.50 above chassis frame rail

### **Capacity**

40,000 ft-lbs maximum

| <b>LIFTING CAPACITIES</b> |               |                  |                 |
|---------------------------|---------------|------------------|-----------------|
| <b>Distance</b>           | <b>Weight</b> | <b>Extension</b> | <b>Position</b> |
| 8 ft 0 in                 | 5,000 lbs     | 1 <sup>st</sup>  | Retracted       |
| 12 ft 6 in                | 3,200 lbs     | 1 <sup>st</sup>  | Retracted       |
| 17 ft 10 in               | 2,200 lbs     | 1 <sup>st</sup>  | Extended        |
| 23 ft 7 in                | 1,640 lbs     | 2 <sup>nd</sup>  | Extended        |
| 29 ft 4 in                | 1,000 lbs     | 3 <sup>rd</sup>  | Extended        |

The A40 Knuckleboom Crane is rated at the hook on a Specific Section **not** distance divided into Ft-Lb Rating. Once a section is moved out even 1 inch, the capacity falls to the rating fully extended. The exception is a fully retracted single section can lift to 5,000 lbs at 8 ft. See Load Chart

### **Rotation Bearing**

Lubricant: Moly 29  
elf Keystone Lubricants  
1-800-344-2241

### **Chassis Requirements**

17,500 lbs GVWR minimum  
600,000 RBM minimum

### **Hydraulic System**

Pressure: 3500 psi maximum operating  
Individual spool section have  
separate port relief settings.  
See Hydraulic Schematic

Flow: 8 gpm

Filtration: Suction line strainer 100 mesh  
Hydraulic Filter 10 micron in-tank

Hydraulic Reservoir: 12 gals

Oil type: 10w Hydraulic Oil  
Mobile DTE 13, Sun 2015,  
Dextron II

Rotation Motor: 9.8 cid

Inner Boom Cylinder: 5.00 Bore x 14.70 Stroke

Outer Boom Cylinder: 5.00 Bore x 27.75 Stroke

Extension Cylinder: 2.00 Bore x 64.00 Stroke

Outrigger Cylinder: 2.00 Bore x 22.00 Stroke

### **Electrical System Requirements**

Alternator: 60 amp minimum


Battery: Standard Truck Okay

Standard A40 has no electrical requirements



## A40 GENERAL DIMENSION

S






***NOTES***



***A40 LOAD CHART***  
***P/N: 407022000***

**Model A40 Load Chart**



Note: Deduct the Weight of Load Handling Attachment

407022000

The A40 Knuckleboom Crane is rated at the hook on a Specific Section not distance divided into Ft-Lb Rating. Once a section is moved out even 1 inch, the capacity falls to the rating fully extended. The exception is a fully retracted single section can lift to 5,000 lbs at 8 ft.



## **--- IMPORTANT --- SAFETY TIPS AND PRECAUTIONS**

1. No unqualified or unauthorized person shall be allowed to operate the crane.
2. **WARNING:** Never weld, modify, or use unauthorized components / parts on any Auto Crane unit. This will void any warranty or liability. Also, failure of the crane may result.
3. Make certain the vehicle meets minimum chassis requirements. (These requirements do not guarantee unit stability.)
4. Make certain the crane is installed per factory specifications. Contact your local distributor or the Auto Crane factory if any questions arise.
5. Visual inspections and tests should be conducted at the beginning of each shift each day to ensure that the crane and all its operating systems are in good condition and working order before it is used.
6. Inspect hydraulic hoses frequently for signs of deterioration, and replace them as required.
7. If a hydraulic break occurs, leave the area of the break and do not attempt to stop the break by hand as the hydraulic oil may be hot and under high pressure which can cause serious injury. Shut the system down as soon as possible.
8. Check the hook at least every thirty days for distortions or cracks and replace it as required.
9. Oil gears as required.
10. Stop all operations when cleaning, adjusting or lubricating the machine.
11. Keep dirt and grit out of moving parts by keeping a crane clean. Make sure machine is free of excess oil, grease, mud and rubbish, thus reducing accidents and fire hazards.
12. When a new cable is installed, operate first with a light load to let the cable adjust itself.
13. Locate the vehicle at the work site for the best stability possible.
14. Keep the vehicle in a level position while loading or unloading.
15. Observe operating area for obstructions and/or power lines that might be a hazard.
16. **WARNING: NEVER OPERATE THE CRANE NEAR ELECTRICAL POWER LINES.** Auto Crane Company recommends that the crane never be any closer to a power line (including telephone lines) than 10 feet at any point.
17. Allow the vehicle engine to warm up before operating crane.
18. Know the weight of your rigging and load to avoid overloading the crane.
19. Deduct the weight of the load handling equipment from the load rating to determine how much weight can be lifted.
20. All load ratings are based on crane capacity, NOT the vehicle stability.  
Remember in lifting a heavy load, the weight can create enough tipping moment to overturn the vehicle.
21. Always comply with load chart capacities, (centerline of rotation to hook).
22. Secure all loads before lifting.
23. Always set the emergency brake before beginning operation.
24. Keep objects and personnel clear of crane path during operation.
25. Operate control levers slowly and smoothly in order to meter oil flow for safe operation.
26. Always use outriggers from vehicle to the ground during crane operation. Ensure that they are firmly positioned on solid footings. Stand clear of outriggers while they are being extended.
27. If any outrigger, when extended, rests on a curb or other object that prevents it from extending to its maximum distance, shorten bearing or fulcrum point and reduce the maximum load accordingly.
28. When an outrigger will not reach the ground due to holes or grades, it shall be blocked up to provide level and firm support for the truck.
29. When working in soft earth, use wide pads under outrigger feet to prevent sinking.

## **WARNING!**

Auto Crane Company cranes are not designed or intended for use in lifting or moving persons. Any such use shall be considered to be improper and the seller shall not be responsible for any claims arising there from. This sale is made with the express understanding that there is no warranty that the goods shall be fit for the purpose of lifting or moving persons or other improper use and there is no implied warranty or responsibility for such purposes.



## **--- IMPORTANT ---**

### ***SAFETY TIPS AND PRECAUTIONS***

30. Always store outriggers before transportation.
31. Always store the crane in its stowed position for transportation.
32. Remember the overall height of the entire unit for garage door clearance or when moving under objects with low overhead clearance.
33. Disengage power takeoff (PTO) before moving the vehicle.
34. Always walk around the vehicle before moving.
35. Never drive with a load suspended from crane.
36. Do not take your eyes off a moving load. Look in the direction you are moving.
37. Never swing a load over people.
38. Do not stop the load sharply in midair so that it swings like a pendulum. Meter the control levers to avoid this situation.
39. Crane boom length should be kept as short as possible for maximum lifting capacity and greater safety. Longer booms require additional care in accelerating and decelerating the swing motion, and thus slow down the working cycle and reduce productivity.
40. Keep the load directly and vertically under the boom point at all times. Crane booms are designed primarily to handle vertical loads, not side lifts.  
**WARNING: Never attempt to lift, drag, tow or pull a load from the side. The boom can fail far below its rated capacity.**
41. Do not push down on anything with boom extensions, lift or outer boom function.
42. Do not lift personnel with any wire rope attachment or hook. There is no implied warranty or responsibility for such purposes.
43. **WARNING:** In using a safety hook, ALWAYS close the hook throat before lifting a load. Proper attention and common sense applied to the use of the hook and various slings will prevent possible damage to material being hoisted and may prevent injury to personnel.
44. **WARNING:** Never place a chain link on the tip of the hook and try to lift a load with the hoist.
45. **WARNING:** Never use a sling bar or anything larger than the hook throat which could prevent the safety latch from closing, thus negating the safety feature.
46. If the crane is equipped with an optional winch:
  - do NOT allow personnel to ride on loadline, hook, load, or any other device attached to winch line.
  - do NOT extend boom without reeling off line at the same time when using winch.
  - do pull load-block up against the boom tip.
47. Do not wrap the wire rope around sharp objects when using winch.
48. **WARNING:** Never unreel last 5 wraps of cable from drum.




## ***A40 ARTICULATING CRANE MOUNTING and INSTALLATION***

1. Vehicle should meet minimum 17,500 lb. GVW rating and/or a frame resistance to bending of 600,000 in-lbs. minimum, dual rear wheels and tires, engine tachometer and throttle control, and front and rear springs to match axle ratings.
2. Make sure frame is clear of all obstructions in the area where the crane is to be mounted.
3. Distance required between back of cab and front of flatbed or body is 24 in.
4. A40 weight: **1,750 lbs with (1) hydraulic extension**  
**1,860 lbs with (1) hydraulic extension & (1) manual boom**  
**2,040 lbs with (2) hydraulic extension**  
**2,100 lbs with (2) hydraulic extension & (1) manual boom**
5. In preparation for crane mounting, ensure mounting surfaces are flat by having wear plates between the crane base and the top of truck frame rails. Wear plates are as follows: (Fig. 1)
  - ◆ (1) ¼" thick x 3" wide x 25" long flat bar on the driver side.
  - ◆ (1) ¼" thick x 3" wide x 11" long flat bar on the passenger side.

These wear plates should have clearance holes as applicable to clear rivet heads on the truck frame rails.

6. Use lifting eye, ref fig. 2, to lift the crane and position it on the truck frame
7. Once the crane is positioned on the wear plates on the truck, weld (4) stop tabs on wear plates in front and behind of crane mount to prevent the wear plates from moving. Stop tab should be a minimum of ½" thick x 2 ¾" wide x 2" long.



**FIG. 1**

**NOTE: Never weld on truck frame.**




## ***A40 ARTICULATING CRANE MOUNTING and INSTALLATION***

8. Install the mounting hardware, as shown in diagram according to selected Ford chassis.
9. Torque the first set of mounting bolts and nuts to 225 ft-lbs. Torque the second set of mounting bolts and nuts to 100 ft-lbs. Recheck the torques after initial installation testing is performed, after the first 10 hours of operation and once a year thereafter.
10. The Suction & Pressure hoses and fittings are not furnished with this crane. These items are normally determined at installation.
  - A. Suction hose from pump to reservoir: Hose size, 1 inch (-16) SAE 100 R4
  - B. Pressure hose from pump to control valve inlet: Hose size,  $\frac{3}{4}$  inch (-08) with minimum working pressure of 4000 psi.

Install PTO by following PTO's manufacturers installation instructions. It is recommended that PTO mounting bolts be safely wired to prevent bolts from becoming loose. Always check to make sure that there is no transmission oil leaking around the PTO mounting.

**NOTE:** After installation of the pump/PTO and the reservoir is complete, connect the pressure and return lines together. Circulate the hydraulic oil for thirty minutes to trap any contaminants in the system before hooking the pressure and return lines to the crane. Be sure to check filters after purging the system.

11. Crane operation requires 8 gpm at 3800 psi.
12. To insure proper crane operation and crane performance, the vehicle shall be equipped with an engine speed control and tachometer.
13. Always store the crane in the figure-4 position as shown in fig. 2, when not in operation.




**FIG. 2**

14. Lubricate bearing teeth and worm gear teeth as needed using supplied grease.



## ***A40 CRANE INSTALLATION (STANDARD INSTALLATION)***




## **OPTIONAL CRANE INSTALLATION**

HYDRAULIC RESERVOIR REMOVED FOR CLARITY



## ***A40 CRANE INSTALLATION (STANDARD INSTALLATION)***


VIEW OF REAR MOUNTING POINT ON THE PASSENGER SIDE.



| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                           |
|----------|------|-----------|---------------------------------------|
| 1        | 3    | 368087    | PAD MTG                               |
| 2        | 3    | 368088    | PAD BTM MTG                           |
| 3        | 6    | 367182    | ALL THD 1" UNC X 20 LG                |
| 4        | 24   | 367183    | NUT 1" UNC                            |
| 5        | 12   | 407311000 | WASHER FL 1 I.D. x 2.50 O.D. HARDENED |
| 6        | 3    | 407174000 | TBG RT STL 3 X 2 X .250W X 10         |
| 7        | 1    | 407106101 | GREASE - MOLY 29                      |




***A40 CRANE INSTALLATION – (OPTIONAL)  
(ONLY FOR USE WHEN THERE IS AN OBSTRUCTION)  
(REF. – FRAME CROSS MEMBER)***



**OPTIONAL CRANE INSTALLATION**  
(ONLY FOR USE ON THE FORD F-550 TRUCK CHASSIS)  
EXAMPLE: FRAME CROSS MEMBER



***A40 CRANE INSTALLATION – (OPTIONAL)  
(ONLY FOR USE WHEN THERE IS AN OBSTRUCTION)  
(REF. – FRAME CROSS MEMBER)***



| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                           |
|----------|------|-----------|---------------------------------------|
| 1        | 1    | 368087    | PAD MTG                               |
| 2        | 1    | 368088    | PAD BTM MTG                           |
| 3        | 2    | 367182    | ALL THD 1" UNC X 20 LG                |
| 4        | 12   | 367183    | NUT 1" UNC                            |
| 5        | 8    | 407311000 | WASHER FL 1 I.D. x 2.50 O.D. HARDENED |
| 6        | 1    | 407174000 | TBG RT STL 3 X 2 X .250W X 10         |
| 7        | 2    | 407307000 | FRAME MTG BRKT WDMT                   |
| 8        | 2    | 407173000 | SCW HX HD 1" NC X 4.50 LG GR8         |
| 9        | 2    | 407171000 | DOUBLER                               |
| 10       | 4    | 490170000 | SCW HX 5/8 NC X 3 1/4 GR 8            |
| 11       | 8    | 407314000 | WASHER FL 5/8 X 1 5/16 OD HARDENED    |
| 12       | 8    | 407315000 | NUT HX 5/8 NC CP GR8                  |
| 13       | 1    | 407106101 | GREASE - MOLY 29                      |



## **--- IMPORTANT ---**

### **OPERATION OF UNIT**

1. Make sure this manual has been thoroughly read by all crane operating personnel and supervisors. The crane should be operated by qualified personnel only.
2. A daily routine inspection of the crane should be mandatory before each operating day. Any defects should be corrected immediately and before operating the crane.
3. At a job site the vehicle should be positioned so that the crane can adequately reach the load within the rated capacity - centerline of rotation to hoist hook. The job site should be checked for any hazards which might create an unsafe situation for the operator; such as any overhead electrical lines, soft or unlevel ground, etc. When cross grade parking is necessary, restrict the load to compensate for the increased risk of tipping the vehicle.
4. Keep the vehicle as level as possible during operation.
5. **Engage emergency brake & Chock rear wheels**, place gear selector in neutral, press clutch, activate PTO, release clutch and after hydraulic fluid is warm, set throttle control to proper engine speed.
6. Always fully extend outriggers from the truck and hydraulic power down to the ground. Be sure the pads are firm and adequately positioned. When rotating, **keep load as low to the ground as possible**.
7. When unstowing the knuckleboom crane, first retract outer boom cylinder, then extend the inner boom until crane is raised high enough so that in rotation the boom sections will clear any obstructions, i.e. cab, rack, body, etc.
8. Always observe safe and practical operating practices to avoid possible accidents. **NEVER** use two cranes to support a load too large for either crane. Refer to safety tips and precautions.
9. After completing lifting operations, return the boom to stowed figure-4 position for travel. When stowing, begin by retracting the extension cylinder. Retract outer boom cylinder next. Rotate crane into position by aligning up the arrows on the rotation bearing and tower base plate. Retract inner boom cylinder into the figure-4 position. Always stand on the opposite side of the inner boom when stowing and unstowing.
10. Return outriggers to stowed position. Make sure the outrigger slides are pinned in place and outrigger cylinders are fully retracted before traveling.
11. Check work area for any tools or equipment not stored. Store all wheel chocks.
12. Release throttle control, depress clutch and disengage PTO.
13. Report any unusual occurrence during crane operation that may indicate required maintenance or repair.



## ***QUALIFICATIONS FOR AND CONDUCT OF OPERATORS AND OPERATING PRACTICES***

### **OPERATORS**

- 1 Crane operation shall be limited to personnel with the following minimum qualifications:
  - A. designated persons
  - B. trainees under the direct supervision of a designated person
  - C. maintenance and test personnel (when it is necessary in the performance of their duties)
  - D. inspectors (crane).
- 2 No one other than the personnel specified above shall enter the operating area of a crane with the exception of persons such as oilers, supervisors, and those specified persons authorized by supervisors whose duties require them to do so and then only in the performance of their duties and with the knowledge of the operator or other persons.

### **QUALIFICATIONS FOR OPERATORS**

- 3 Operators shall be required by the employer to pass a practical operating examination. Qualifications shall be limited to the specific type of equipment for which examined.
- 4 Operators and operator trainees shall meet the following physical qualifications:
  - A. Vision of at least 20/30 Snellen in one eye and 20/50 in the other, with or without corrective lenses.
  - B. Ability to distinguish colors, regardless of position, if colors differentiation is required for operation.
  - C. Adequate hearing with or without hearing aid for the specific operation.
- 5 Evidence of physical defects or emotional instability which render a hazard to operator or others, which in the opinion of the examiner could interfere with the operator's performance may be sufficient cause for disqualification. In such cases, specialized clinical or medical judgment and tests may be required.
- 6 Evidence that the operator is subject to seizures or loss of physical control shall be sufficient reason for disqualification. Specialized medical tests may be required to determine these conditions.
- 7 Operators and operator trainees should have normal depth perception, coordination, and no

tendencies to dizziness or similar undesirable characteristics.

- 8 In addition to the above listed requirements, the operator shall:
  - A. Demonstrate the ability to comprehend and interpret all labels, operator's manuals, safety codes and other information pertinent to correct crane operations.
  - B. Possess knowledge of emergency procedures and implementation of same.
  - C. Demonstrate to the employer the ability to operate the specific type of equipment.
  - D. Be familiar with the applicable safety regulations.
  - E. Understand responsibility for maintenance requirements of crane.
  - F. Be thoroughly familiar with the crane and its control functions.
  - G. Understand the operating procedures as outlined by the manufacturer.

### **CONDUCT OF OPERATORS**

- 9 The operator shall not engage in any practice which will divert his attention while actually operating the crane.
- 10 Each operator shall be responsible for those operations under the operator's direct control. Whenever there is any doubt as to safety, the operator shall consult with the supervisor before handling the loads.
- 11 The operator should not leave a suspended load unattended unless specific precautions have been instituted and are in place.
- 12 If there is a warning sign on the switch or engine starting controls, the operator shall not close the switch or start the engine until the warning sign has been removed by the appointed person.
- 13 Before closing the switch or starting the engine, the operator shall see that all controls are in the "OFF" or neutral position and all personnel are in the clear.
- 14 If power fails during operation, the operator shall:
  - A. move power controls to the "OFF" or neutral position.
  - B. land the suspended load and boom, if practical.
- 15 The operator shall be familiar with the equipment and its proper care. If adjustments or repairs are necessary, the operator shall report the same promptly to the appointed person, and shall also notify the next operator.



## ***QUALIFICATIONS FOR AND CONDUCT OF OPERATORS AND OPERATING PRACTICES***

16 All controls shall be tested by the operator at the start of each shift. If any controls do not operate properly, they shall be adjusted or repaired before operations are begun.

17 Stabilizers shall be visible to the operator while extending or setting unless operator is assisted by a signal person.

### **OPERATING PRACTICES** **HANDLING THE LOAD**

#### **18 Size of load**

- A. No crane shall be loaded beyond the rated load except for test purposes.
- B. The load to be lifted is to be within the rated load of the crane and its existing configuration.
- C. When loads which are not accurately known are to be lifted, the person responsible for the job shall ascertain that the weight of the load does not exceed the crane rated load at the radius at which the load is to be lifted.

#### **19 Attaching the load**

- A. The load shall be attached to the hook by means of slings or other devices of sufficient capacity.
- B. Hoist rope shall not be wrapped around the load.

#### **20 Moving the load**

- A. The operator shall determine that:
- B. The crane is level and, where necessary, the vehicle/carrier is blocked properly.
- C. The load is well secured and balanced in the sling or lifting device before it is lifted more than a few inches.
- D. Means are provided to hold the vehicle stationary while operating the crane.
- E. Before starting to lift, the hook shall be brought over the load in such a manner as to minimize swinging.
- F. During lifting care shall be taken that:
  - 1. there is no sudden acceleration or deceleration of the moving load.
  - 2. load, boom or other parts of the crane do not contact any obstruction.

G. Cranes shall not be used for dragging loads sideways

H. This standard recognizes that articulating boom cranes are designed and intended for handling materials. They do not meet personnel lift or elevator requirements. Therefore, no lifting, lowering, swinging or traveling shall be done while a person is on the hook or load. Hook attached suspended work platforms (baskets) shall not be used with cranes covered by this standard. Work platforms attached to the boom must be approved by crane manufacturer.

I. The operator should avoid carrying loads over people.

J. When the crane is so equipped, the stabilizers shall be fully extended and set. Blocking under stabilizers shall meet the requirements as follows:

- 1. strong enough to prevent crushing.
- 2. of such thickness, width and length as to completely support the stabilizer pad.

K. Firm footing under all tires, or individual stabilizer pads should be level. Where such a footing is not otherwise supplied, it should be provided by timbers, cribbing, or other structural members to distribute the load so as to not exceed allowable bearing capacity or the underlying material.

L. In transit, the boom shall be carried in stowed position.

M. When rotating the crane, sudden starts and stops shall be avoided. rotational speed shall be such that the load does not swing out beyond the radius at which it can be controlled.

N. The crane shall not be transported with a load on the hook unless recommended by the manufacturer.

O. No person should be permitted to stand or pass under a suspended load.


21 Stowing procedure. Follow the manufacturer's procedure and sequence when stowing and un-stowing the crane.



# QUALIFICATIONS FOR AND CONDUCT OF OPERATORS AND OPERATING PRACTICES

## MISCELLANEOUS

### OPERATING NEAR ELECTRICAL POWER LINES



- 22 Cranes shall be operated so that no part of the crane or load enters into the danger zone shown above.

### EXCEPTIONS

- A. The danger zone may be entered after confirmation by an appointed person that the electrical distribution and transmission lines have been de-energized and visibly grounded at the point of work; or
- B. The danger zone may be entered if insulating barriers (not a part of nor an attachment to the crane) have been erected to prevent physical contact with the lines.
- 23 For lines rated 50 kV or below, minimum clearance between the lines and any part of the crane or load (including handling appendages) shall be 10 ft. (3m). For higher voltages, see Table 1.
- 24 Caution shall be exercised when working near overhead lines, because they can move horizontally or vertically due to wind, moving the danger zone to new positions.

- 25 In transit with no load and boom lowered the clearance shall be specified in Table 1.
- 26 A qualified signalperson shall be assigned to observe the clearance and give warning before approaching the above limits.
- A. Any overhead wire shall be considered to be an energized line unless and until the person owning such line or the electrical utility authorities verify that it is not an energized line.
- B. Exceptions to this procedure, if approved by the administrative or regulatory authority if the alternate procedure provides equivalent protection and set forth in writing.
- C. Durable signs shall be installed at the operator's station and on the outside of the crane, warning that electrocution or serious bodily injury may occur unless a minimum clearance of 10 ft. (3.0m) between the crane or the load being handled and energized power lines. Greater clearances are required because of higher voltage as stated above. These signs shall be revised but not removed when local jurisdiction requires greater clearances.

**TABLE 1**

| normal voltage, kV<br>(phase to phase)                |             | minimum required<br>clearance |         |
|-------------------------------------------------------|-------------|-------------------------------|---------|
|                                                       |             | ft                            | (m)     |
| <u>when operating near high voltage power lines</u>   |             |                               |         |
| over                                                  | to 50       | 10                            | (3.05)  |
| over                                                  | 50 to 200   | 15                            | (4.6)   |
| over                                                  | 200 to 350  | 20                            | (6.1)   |
| over                                                  | 350 to 500  | 25                            | (7.62)  |
| over                                                  | 500 to 750  | 35                            | (10.67) |
| over                                                  | 750 to 1000 | 45                            | (13.72) |
| <u>while in transit with no load and boom lowered</u> |             |                               |         |
| over                                                  | to 0.75     | 4                             | (1.22)  |
| over                                                  | 0.75 to 50  | 6                             | (1.83)  |
| over                                                  | 50 to 345   | 10                            | (3.83)  |
| over                                                  | 345 to 750  | 16                            | (4.87)  |
| over                                                  | 750 to 1000 | 20                            | (6.1)   |



## ***INSPECTION, TESTING AND MAINTENANCE GENERAL***

### **INSPECTION CLASSIFICATION**

- 1 Initial inspection. Prior to initial use, all new, altered, modified or extensively repaired cranes shall be inspected by a designated person to insure compliance with provisions of this standard.
- 2 Regular inspection. Inspection procedure for cranes in regular service is divided into two general classifications based upon the intervals at which inspection should be performed. The intervals in turn are dependent upon the nature of the components of the crane and the degree of their exposure to wear, deterioration, or malfunction. The two general classifications are herein designated as "frequent" and "periodic" with respective intervals between inspections as defined below.
  - A. frequent inspection - daily to monthly intervals
  - B. periodic inspection - one to twelve intervals, or as specifically recommended by the manufacturer

### **FREQUENT INSPECTION**

- 3 Inspection shall be performed by designated personnel.
  - A. control mechanisms for maladjustment interfering with proper operation - daily, when used
  - B. control mechanisms for excessive wear of components and contamination by lubricants or other foreign matter
  - C. safety devices for malfunction
  - D. all hydraulic hoses, particularly those which flex in normal operation of crane functions, should be visually inspected once every working day, when used
  - E. hooks and latches for deformation, chemical damage, cracks, and wear. Refer to ANSI/ASME B30.10
  - F. rope reeving for compliance with crane manufacturer's specifications, if optional winch is used
  - G. electrical apparatus for malfunctioning, signs of excessive deterioration, dirt and moisture accumulation
  - H. hydraulic system for proper oil level and leaks daily
  - I. tires for recommended inflation pressure, cuts and loose wheel nuts
  - J. connecting pins and locking device for wear and damage

### **PERIODIC INSPECTION**

- 4 Deformed, cracked or corroded members in the crane structure and carrier.
- 5 Loose bolts, particularly mounting and rotation bolts.
- 6 Cracked or worn sheaves and drums.
- 7 Worn, cracked, or distorted parts such as pins, bearings, shafts, gears, rollers and devices.
- 8 Excessive wear on brake and clutch system parts and lining.
- 9 Crane hooks inspected for cracks.
- 10 Travel steering, braking, and locking devices, for malfunction.
- 11 Excessively worn or damaged tires.
- 12 Hydraulic and pneumatic hose, fittings, and tubing inspection.
  - A. evidence of leakage at the surface of the flexible hose or its junction with metal and coupling
  - B. blistering, or abnormal deformation to the outer covering of the hydraulic or pneumatic hose
  - C. leakage at threaded or clamped joints that cannot be eliminated by normal tightening or recommended procedures
  - D. evidence of excessive abrasion or scrubbing on the outer surface of a hose, rigid tube, or fitting. Means shall be taken to eliminate the interference of elements in contact or otherwise protect the components
- 13 Hydraulic and pneumatic pumps and motors inspection.
  - A. loose bolts or fasteners
  - B. leaks at joints between sections
  - C. shaft seal leaks
  - D. unusual noises or vibrations
  - E. loss of operating speed
  - F. excessive heating of the fluid
  - G. loss of pressure
- 14 Hydraulic and pneumatic valves inspection.
  - A. cracks in valve housing
  - B. improper return of spool to neutral position
  - C. leaks at spools or joints
  - D. sticking spools
  - E. failure of relief valves to attain or maintain correct pressure setting
  - F. relief valve pressure shall be checked as specified by the manufacturers



## ***INSPECTION, TESTING AND MAINTENANCE***

### ***GENERAL***

#### **15 Hydraulic and pneumatic cylinders inspection.**

- A. drifting caused by fluid leaking across piston
  - B. rod seals leaking
  - C. leaks at welding joints
  - D. scored, nicked, or dented cylinder rods
  - E. damaged case (barrel)
  - F. loose or deformed rod eyes or connecting joint-
- sHydraulic filters. Evidence of rubber particles on the filter elements may indicate hose, "O" ring, or other rubber component deterioration. Metal chips or pieces on the filter may denote failure in pumps, motors, or cylinders. Further checking will be necessary to determine origin of the problem before corrective action can be taken.

**Operational crane test results shall be made available to an appointed person.**

#### **16 Labels are to be in place and legible.**

### **CRANES NOT IN REGULAR USE**

**17** A crane which has been idle for a period of over one month or more, but not less than six months, shall be given an inspection conforming with the initial-regular- frequent inspections.

**18** A crane which has been idle for a period of over six months shall be given a complete inspection conforming with the initial-regular-frequent inspection requirements.

### **INSPECTION RECORDS**

**19** Dated records for periodic inspection should be made on critical items such as brakes, crane hooks, rope, hydraulic and pneumatic cylinders, and hydraulic and pneumatic relief pressure valves. Records should be kept available to an appointed person.

### **OPERATIONAL TESTS**

**20** Prior to initial use, all new, altered, modified, or extensively repaired cranes shall be tested for compliance with the operational requirements of this section, including functions such as the following:

- A. load lifting and lowering mechanisms
- B. boom lifting and lowering mechanisms
- C. boom extension and retraction mechanisms
- D. swing mechanisms
- E. safety devices
- F. operating controls comply with appropriate function labels



## ***INSPECTION, TESTING AND MAINTENANCE***

### ***GENERAL***

#### **RATED TEST LOAD**

**Prior to initial use, altered, modified, or extensively repaired cranes shall be load tested by or under the direction of an appointed person.**

- 21 Test loads shall not exceed 110% of the manufacturer's load ratings.
- 22 Written reports shall be maintained showing test procedures and confirming the adequacy of repairs.

#### **MAINTENANCE**

##### **PREVENTIVE MAINTENANCE**

- 23 Before adjustment and repairs are started on a crane, the following precautions shall be taken as applicable:

- A. crane placed where it will cause the least interference with other equipment or operations
  - B. all controls at the "off" position
  - C. starting means rendered inoperative
  - D. boom lowered to the ground if possible or otherwise secured against dropping
  - E. relieve hydraulic oil pressure from all hydraulic circuits before loosening or removing hydraulic components
- 24 Warning or "OUT OF ORDER" signs shall be placed on the crane controls.
  - 25 After adjustments and repairs have been made, the crane shall not be returned to service until all guards have been reinstalled, trapped air removed from hydraulic system (if required), safety devices reactivated, and maintenance equipment removed.



## ***ROTATION BEARING & WORM DRIVE LUBRICATION***

### **ROTATION BEARING RACE**

Lubricate bearing race at the grease zerk located inside the tower through access panel on front face.

Listed in the chart below are several lubricants which are acceptable for both rust inhibiting and extreme pressure characteristics:

- Lubricate the inner race daily if crane is used continuously each day or weekly with normal use.
- Lubricate the inner race every 30 days if the crane is used intermittently.
- Rotate the bearing through two or more rotations during lubrication process.

### **WORM DRIVE LUBRICATION**

Lubricate worm drive bearings at the two grease zerk located at lower outside of worm housing. This should be done at same time bearing race is lubricated

Listed in the chart below are several lubricants which are acceptable for both rust inhibiting and extreme pressure characteristics:

- Lubricate the worm drive daily if crane is used on a daily basis or weekly with normal use.
- Lubricate the worm drive every 30 days if the crane is used intermittently.

### **RING GEAR**

Recommends **Keystone Moly 29** for the ring gear. It is a Molybdenum Disulfide based lubricant that is very tacky and can stand high pressure and temperature. It is recommended that the teeth be lubricated with a small amount of grease every 8 hours if the crane is used daily, or weekly with normal use. The grease is purged from the teeth by the very nature of being exposed to the elements. Therefore close attention to gear lubricant will provide a longer tooth life.

NOTE: Regular periodic lubrication is the most effective way to increase the life and service ability of the rotation bearing. Most bearings are used outdoors and under conditions likely to produce internal condensation.

| MOBILE          | TEXACO      | SUNOCO          | PURE         | SOHIO        |
|-----------------|-------------|-----------------|--------------|--------------|
| Mobil Plex EP 2 | MARFAC MP 2 | Prestige 742 EP | Poco HT EP 2 | Sohitran EP1 |



## ***OIL SELECTION***

### **ALL WEATHER OILS**

MOBIL DTE 13  
MOBIL DTE 15  
TEXACO URSA SUPER 3 SEA 10W  
GULF XHD 10W/30  
TEXACO RONDO HDAZ-32  
ESSO UNIVIS J 26

### **WARM WEATHER OILS**

MOBILE DELVAC 1210  
TEXACO URSATEX 10W/30  
ESSO NUTO H 32  
MOBIL DELVAC SPECIAL 10W/30 UNIVERSAL  
TRACTOR FLUID

### **COLD WEATHER OILS**

MOBIL DTE 11  
CONOCO DN 600  
ESSO UNIVIS J 13

### **CAUTION:**

**Do not add kerosene or other "thinners" to hydraulic oil. These fluids will cause swelling and rapid deterioration of o-rings and other seals in the hydraulic system.**

The reservoir of the crane contains approximately 19-25 gals. (72-95 liters) of hydraulic oil, depending on the model. Oil level should be maintained at the full mark shown on the sight gauge with all cylinders in the retracted or stowed position.

If there is any question regarding the condition of the hydraulic oil, drain some of the oil from the bottom of the reservoir into a glass container and inspect for the following indications of deterioration:

- 1 Dark color or cloudy appearance
- 2 A rancid or burned odor
- 3 Foreign particles or other contaminants
- 4 A loss of viscosity
- 5 A separation of water or other fluids from the oil

If the sample checked exhibits any of the above characteristics, an oil change is recommended as outlined previously.

### **HYDRAULIC OIL**

Hydraulic oil is the "LIFEBLOOD" of the crane. Proper selection and care is important to provide the most efficient operation and the longest life from each of the hydraulic components in the crane. Hydraulic oil not only transmits the energy required operate the machine from the pump to the various cylinders and motors, but also provides for lubrication and cooling of the components. It is often said that oil does not wear out and can be left in a crane indefinitely, providing the filters are changed regularly. Good filtration does prolong the life of hydraulic oil, but its lubrication characteristics are diminished as it becomes diluted by condensation, acids and other non-filterables which form during normal use of the crane.

It is recommended that the hydraulic reservoir be drained and refilled with new oil after each 500 hours of operation. In climates that have a wide variation of operating temperature, it is recommended that oil of the appropriate weight be used for cold and warm weather operation.

In the event that the hydraulic system becomes contaminated with metallic particles due to a motor, pump or other component failure, the following should be done immediately to prevent failure to the crane:

- 1 Drain the oil reservoir completely.
- 2 Fill the reservoir 1/2 full with clean hydraulic oil to flush the contaminated oil from the cylinders and hydraulic lines of the system.

**NOTE:** Operate each function to the full open and closed position several times.

- 3 Operate the system at a slow RPM to prevent cavitation of the pump.
- 4 Drain the reservoir completely again.
- 5 Change the return and suction filters
- 6 Refill the reservoir to the full line on the sight glass.
- 7 Allow the new oil to circulate through the system for several minutes before operating the unit.
- 8 Change the return line filter again after approximately 25 hours of operation.



## ***LUBRICATION & MAINTENANCE SCHEDULE A40 CRANE***

| SERVICE PERFORMED               | DAY                                                                 | WEEKLY | 3 MOS | YEAR | NOTES                                                                                                         |
|---------------------------------|---------------------------------------------------------------------|--------|-------|------|---------------------------------------------------------------------------------------------------------------|
| LOAD HOOK                       | X                                                                   |        |       |      | INSPECT HOOK & LATCH FOR DEFORMATION, CRACKS, & CORROSION                                                     |
| HYD HOSES                       | X                                                                   |        |       |      | VISUAL INSPECTION, REPLACE IF DAMAGED                                                                         |
| HYD FLUID                       | X                                                                   |        |       |      | CHECK FLUID LEVEL, FILL AS REQUIRED                                                                           |
| MOUNTING BOLTS                  |                                                                     | X      |       |      | CHECK TORQUE TO 225 FT-LBS (DRY) AS REQUIRED                                                                  |
| ROTATION RING GEAR              | X                                                                   | X      |       |      | WITH CONTINUOUS 8 HR USE, APPLY DAILY OTHERWISE WEEKLY WITH MOLY 29 from elf KEYSTONE Lubricants 800 344-2241 |
| ALL OTHER BOLTS                 |                                                                     | X      |       |      | CHECK & TIGHTEN AS REQUIRED                                                                                   |
| ALL CYLINDERS                   |                                                                     | X      |       |      | CHECK AROUND CYLINDER RODS FOR EXCESS FLUID LEAKAGE                                                           |
| ALL CYLINDER PINS               |                                                                     | X      |       |      | CHECK FOR DAMAGE AND LOOSE MOUNTING HARDWARE                                                                  |
| BOOM PADS                       |                                                                     | X      |       |      | REPLACE WHEN 1/16 <sup>TH</sup> THICK                                                                         |
| RETURN LINE FILTER              |                                                                     |        | X     |      | REPLACE ELEMENT                                                                                               |
| ROTATION BEARING                |                                                                     |        | X     |      | GREASE WITH MOBILPLEX EP-2 OR EQUIVALENT @ ZERKS                                                              |
| WORM DRIVE BEARINGS             |                                                                     |        | X     |      | GREASE WITH MOBILPLEX EP-2 OR EQUIVALENT @ ZERKS                                                              |
| ROTATION BEARING BOLTS          |                                                                     |        | X     |      | RE-TORQUE TO 150 FT-LBS (DRY) AS REQUIRED                                                                     |
| HYDRAULIC FLUID                 |                                                                     |        |       | X    | DRAIN, FLUSH, AND REFILL WITH DTE 13, OR EQUIVALENT                                                           |
| FOR ADDITIONAL INFORMATION SEE: | 1) OWNER'S MANUAL<br>2) OSHA SECTION 1910.180<br>3) ANSI B30.5-1989 |        |       |      |                                                                                                               |

**CAUTION:** Routine maintenance insures trouble-free operation and protects your investment.  
All warranties are void if maintenance is neglected.


**NOTES:**

1. Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.
2. Once a bolt has been torqued to its rated capacity and then removed; the bolt should be replaced with a new one.
3. Auto Crane Company recommends that this crane be serviced per "Crane Inspection Log" P/N 999978. These logs should be filled in at the intervals noted and kept as a permanent record.



## ***A40 CRANE ASSEMBLY - STD***

### ***P/N: 407000000***






## ***A40 CRANE ASSEMBLY - STD***

### ***P/N: 407000000***

| ITEM NO.                | QTY.      | PART NO.                           | DESCRIPTION                         |
|-------------------------|-----------|------------------------------------|-------------------------------------|
| 1                       | 1         | 407100000                          | BASE ASSY                           |
| 2                       | 1         | 407151001                          | TOWER WELDMENT                      |
| 3                       | 1         | 407205001                          | INNER BOOM WDMT                     |
| * 4                     | 1         | 407295000                          | OUTER BOOM ASSY 1 HYD EXT           |
| 5                       | 1         | 407516000                          | CYL OUTER BOOM 5 X 27.75 X 2.50 ROD |
| 6                       | 1         | 407051000                          | CYL INNER BOOM 5 X 14.75 X 2 ROD    |
| 7                       | 1         | 407207000                          | PIN WDMT 2 OD x 8.38                |
| 8                       | 4         | 366394                             | BEARING, PIVOT                      |
| 9                       | 3         | 407242000                          | PIN WDMT 2 OD x 9.75                |
| 10                      | 1         | 466232                             | PIN BLOCK 1 OD                      |
| 11                      | 2         | 360124000                          | PIN HITCH                           |
| 12                      | 1         | 407216000                          | HOSE RETAINER 4.75 WIDE             |
| 13                      | 1         | 407217000                          | HOSE RETAINER 2.50 WIDE             |
| 14                      | 2         | 021200                             | WASHER FL 3/8                       |
| 15                      | 2         | 017301                             | NUT HX LOCK 3/8 NCCP                |
| 16                      | 1         | 407207001                          | PIN WDMT 2 OD x 8.75                |
| 17                      | 1         | 407161000                          | COVER PL A40 TOWER                  |
| 18                      | 4         | 020200                             | WASHER SPLIT LOCK 1/4               |
| 19                      | 4         | 005406                             | SCW HX 1/4-28 X 1/2                 |
| 20                      | 13        | 021100                             | WASHER SPLK 3/8                     |
| 21                      | 2         | 008701                             | SCW HX 3/8 UNC X 7/8 GR5            |
| 22                      | 3         | 008702000                          | SCW HX 3/8-16 X 1 1/4 GR5           |
| 23                      | 18        | 021801                             | WASHER FL 5/8 X 1 5/16 OD           |
| 24                      | 18        | 366393                             | HEX HEAD 5/8-11 X 2.5 GR8           |
| 25                      | 8         | 008400                             | SCW HEX HD 3/8-16 UNC X 3/4 GR 5    |
| 26                      | 1         | 407065000                          | HYD TANK ASSY 12 GAL                |
| 27                      | 1         | 407061000                          | A40 HYD DIAGRAM                     |
| 28                      | 1         | 407020000                          | DECAL LAYOUT A40                    |
| 29                      | 1         | 407030000                          | SHIP KIT A40                        |
| 30                      | 1         | 200197                             | HOOK SWIVEL 3 METRIC TON            |
| 31                      | 2         | 407218000                          | SPACER 2.031 ID X .375              |
| 32                      | 1         | 407135000                          | COVER ROTATION GEAR                 |
| <b>* OPTIONAL BOOMS</b> |           |                                    |                                     |
| CRANE ASSY              | BOOM      | DESCRIPTION                        |                                     |
| 407000001               | 407296000 | OUTER BOOM ASSY 1 HYD EXT 1 MANUAL |                                     |
| 407000002               | 407280000 | OUTER BOOM ASSY 2 HYD EXT          |                                     |
| 407000003               | 407297000 | OUTER BOOM ASSY 2 HYD EXT 1 MANUAL |                                     |



## ***A40 CRANE ASSEMBLY - STD W/7 FUNCTION CONTROL VALVE - P/N: 407002000***






## ***A40 CRANE ASSEMBLY - STD W/7 FUNCTION CONTROL VALVE - P/N: 407002000***

| ITEM NO.                | QTY.      | PART NO.                           | DESCRIPTION                         |
|-------------------------|-----------|------------------------------------|-------------------------------------|
| 1                       | 1         | 407300000                          | BASE ASSY                           |
| 2                       | 1         | 407151001                          | TOWER WELDMENT                      |
| 3                       | 1         | 407205001                          | INNER BOOM WDMT                     |
| * 4                     | 1         | 407295000                          | OUTER BOOM ASSY 1 HYD EXT           |
| 5                       | 1         | 407516000                          | CYL OUTER BOOM 5 X 27.75 X 2.50 ROD |
| 6                       | 1         | 407051000                          | CYL INNER BOOM 5 X 14.75 X 2 ROD    |
| 7                       | 1         | 407207000                          | PIN WDMT 2 OD x 8.38                |
| 8                       | 4         | 366394                             | BEARING, PIVOT                      |
| 9                       | 3         | 407242000                          | PIN WDMT 2 OD x 9.75                |
| 10                      | 1         | 466232                             | PIN BLOCK 1 OD                      |
| 11                      | 2         | 360124000                          | PIN HITCH                           |
| 12                      | 1         | 407216000                          | HOSE RETAINER 4.75 WIDE             |
| 13                      | 1         | 407217000                          | HOSE RETAINER 2.50 WIDE             |
| 14                      | 2         | 021200                             | WASHER FL 3/8                       |
| 15                      | 2         | 017301                             | NUT HX LOCK 3/8 NCCP                |
| 16                      | 1         | 407207001                          | PIN WDMT 2 OD x 8.75                |
| 17                      | 1         | 407161000                          | COVER PL A40 TOWER                  |
| 18                      | 4         | 020200                             | WASHER SPLIT LOCK 1/4               |
| 19                      | 4         | 005406                             | SCW HX 1/4-28 X 1/2                 |
| 20                      | 13        | 021100                             | WASHER SPLK 3/8                     |
| 21                      | 2         | 008701                             | SCW HX 3/8 UNC X 7/8 GR5            |
| 22                      | 3         | 008702000                          | SCW HX 3/8-16 X 1 1/4 GR5           |
| 23                      | 18        | 021801                             | WASHER FL 5/8 X 1 5/16 OD           |
| 24                      | 18        | 366393                             | HEX HEAD 5/8-11 X 2.5 GR8           |
| 25                      | 8         | 008400                             | SCW HEX HD 3/8-16 UNC X 3/4 GR 5    |
| 26                      | 1         | 407065000                          | HYD TANK ASSY 12 GAL                |
| 27                      | 1         | 407061001                          | A40 HYD DIAGRAM 7 FUNCT 1 HYD EXT   |
| 28                      | 1         | 407025000                          | DECAL LAYOUT A40 7 FUNCTION         |
| 29                      | 1         | 407030000                          | SHIP KIT A40                        |
| 30                      | 1         | 200197                             | HOOK SWIVEL 3 METRIC TON            |
| 31                      | 2         | 407218000                          | SPACER 2.031 ID X .375              |
| 32                      | 1         | 407135000                          | COVER ROTATION GEAR                 |
| <b>* OPTIONAL BOOMS</b> |           |                                    |                                     |
| CRANE ASSY              | BOOM      | DESCRIPTION                        |                                     |
| 407002001               | 407296000 | OUTER BOOM ASSY 1 HYD EXT 1 MANUAL |                                     |
| 407002002               | 407280000 | OUTER BOOM ASSY 2 HYD EXT          |                                     |
| 407002003               | 407297000 | OUTER BOOM ASSY 2 HYD EXT 1 MANUAL |                                     |



## ***A40 OUTRIGGER ASSEMBLY***

***P/N: 407302000***






***A40 OUTRIGGER ASSEMBLY***  
***P/N: 407302000***

| ITEM | QTY | PART NO   | DESCRIPTION                   |
|------|-----|-----------|-------------------------------|
| 1    | 2   | 407115000 | SLIDE WELDMENT CS/SS          |
| 2    | 2   | 407050000 | CYLINDER OUTRIGGER            |
| 3    | 8   | 023800    | WASHER SP LK 5/8              |
| 4    | 4   | 490172    | SCW HX 5/8 NC X 1 1/2 LG      |
| 5    | 4   | 490306    | HX HD 5/8-11 X 2.00 GR8       |
| 6    | 2   | 407138000 | HANDLE WDMT OUTRIGGER         |
| 7    | 4   | 480024    | MOUNT PENDANT CABLE RETAINER  |
| 8    | 4   | 020600    | WASHER SP LK 5/16 NC          |
| 9    | 4   | 007807    | SCW HEX 5/16-18 3/4LG GR5     |
| 10   | 1   | 407303000 | HOSE & FITTING KIT OUTRIGGERS |



## ***A40 OUTRIGGER ASSEMBLY W/8" LONGER CYLINDER - P/N: 407302800***






***A40 OUTRIGGER ASSEMBLY  
W/8" LONGER CYLINDER - P/N: 407302800***

| ITEM | QTY | PART NO   | DESCRIPTION                   |
|------|-----|-----------|-------------------------------|
| 1    | 2   | 407115000 | SLIDE WELDMENT CS/SS          |
| 2    | 2   | 407050800 | CYL OUTRIGGER W/8" LONGER ROD |
| 3    | 8   | 023800    | WASHER SP LK 5/8              |
| 4    | 4   | 490172    | SCW HX 5/8 NC X 1 1/2 LG      |
| 5    | 4   | 490306    | HX HD 5/8-11 X 2.00 GR8       |
| 6    | 2   | 407138000 | HANDLE WDMT OUTRIGGER         |
| 7    | 4   | 480024    | MOUNT PENDANT CABLE RETAINER  |
| 8    | 4   | 020600    | WASHER SP LK 5/16 NC          |
| 9    | 4   | 007807    | SCW HEX 5/16-18 3/4LG GR5     |
| 10   | 1   | 407303000 | HOSE & FITTING KIT OUTRIGGERS |



## ***A40 BASE ASSEMBLY***

### ***P/N: 407100000***



**NOTE:**

1. BOLTS SHOULD BE TORQUED TO THE MAXIMUM VALUE RECOMMENDED. TIGHTENING AND TORQUING THE BOLTS SHOULD BE IN INCREMENTAL STEPS AND START WITH THOSE AT THE 12, 6, AND 9 O'CLOCK POSITIONS.
2. LUBRICATE ALL EXPOSED GEAR TEETH WITH EXTERNAL GEAR LUB.
3. LUBRICATION OF THE RACEWAY SHOULD TAKE PLACE EVERY (8) HOURS IN SECERE DUTY APPLICATIONS OR IN DUSTY OR WET ENVIROMENTS.




***A40 BASE ASSEMBLY***  
***P/N: 407100000***

| ITEM | QTY | PART NO   | DESCRIPTION                   |
|------|-----|-----------|-------------------------------|
| 1    | 1   | 407101001 | BASE WDMT                     |
| 2    | 1   | 407106001 | BEARING ROTATION W/HYD MOTOR  |
| 3    | 23  | 021801    | WASHER FL 5/8 X 1 5/16 OD     |
| 4    | 23  | 407118000 | SCW HX HD 5/8-11 X 3 1/2 GR8  |
| 5    | 4   | 020600    | WASHER SP LK 5/16 NC          |
| 6    | 4   | 007401    | SCW 5/16-18 X 1/2 LG          |
| 7    | 8   | 020901    | WASHER FL 5/16                |
| 8    | 8   | 811029    | SCW HX 5/16 NC X 2 1/2        |
| 9    | 8   | 016801    | NUT HEX-LOCK 5/16 NC          |
| 10   | 1   | 407133000 | STOP PUSH ROD WDMT            |
| 11   | 1   | 407130000 | STOP TAB                      |
| 12   | 1   | 407140000 | STOP LINKAGE ASSY             |
| 13   | 1   | 021200    | WASHER FL 3/8                 |
| 14   | 2   | 017301    | NUT HX LOCK 3/8 NCCP          |
| 15   | 1   | 330372    | NUT HEX 3/8-16 UNC            |
| 16   | 1   | 407078000 | CONTROL VALVE SUB-ASSY 5 SECT |



## ***A40 BASE ASSEMBLY W/7 FUNCTION CONTROL VALVE - P/N: 407300000***



**NOTE:**

1. BOLTS SHOULD BE TORQUED TO THE MAXIMUM VALUE RECOMMENDED. TIGHTENING AND TORQUING THE BOLTS SHOULD BE IN INCREMENTAL STEPS AND START WITH THOSE AT THE 12, 6, AND 9 O'CLOCK POSITIONS.
2. LUBRICATE ALL EXPOSED GEAR TEETH WITH EXTERNAL GEAR LUB.
3. LUBRICATION OF THE RACEWAY SHOULD TAKE PLACE EVERY (8) HOURS IN SECERE DUTY APPLICATIONS OR IN DUSTY OR WET ENVIROMENTS.




***A40 BASE ASSEMBLY***  
***W/7 FUNCTION CONTROL VALVE - P/N: 407300000***

| ITEM | QTY | PART NO   | DESCRIPTION                   |
|------|-----|-----------|-------------------------------|
| 1    | 1   | 407101001 | BASE WDMT                     |
| 2    | 1   | 407106001 | BEARING ROTATION W/HYD MOTOR  |
| 3    | 23  | 021801    | WASHER FL 5/8 X 1 5/16 OD     |
| 4    | 23  | 407118000 | SCW HX HD 5/8-11 X 3 1/2 GR8  |
| 5    | 4   | 020600    | WASHER SP LK 5/16 NC          |
| 6    | 4   | 007401    | SCW 5/16-18 X 1/2 LG          |
| 7    | 8   | 020901    | WASHER FL 5/16                |
| 8    | 4   | 811029    | SCW HX 5/16 NC X 2 1/2        |
| 9    | 8   | 016801    | NUT HEX-LOCK 5/16 NC          |
| 10   | 1   | 407133000 | STOP PUSH ROD WDMT            |
| 11   | 1   | 407130000 | STOP TAB                      |
| 12   | 1   | 407140000 | STOP LINKAGE ASSY             |
| 13   | 1   | 021200    | WASHER FL 3/8                 |
| 14   | 2   | 017301    | NUT HX LOCK 3/8 NCCP          |
| 15   | 1   | 330372    | NUT HEX 3/8-16 UNC            |
| 16   | 1   | 407079000 | CONTROL VALVE SUB-ASSY 7 SECT |
| 17   | 4   | 811056    | SCW HX 5/16 NC X 4 LG         |



**SEAL KIT**  
**P/N: 407106002**




**SEAL KIT FOR 407106001**

| ITEM | QTY | PART NO. | DESCRIPTION              |
|------|-----|----------|--------------------------|
| 1    | 1   | REF      | SEAL NAT'L #471818       |
| 2    | 1   | REF      | O'RING RLH#OR-151N73038  |
| 3    | 2   | REF      | SEAL RLH21252875-375BYP2 |
| 4    | 1   | REF      | GASKET MOTOR 2A MAG      |



## ***WORM REPLACEMENT KIT***

***P/N: 407106003***




### **WORM REPLACEMENT KIT FOR 407106001**

| ITEM | QTY | PART NO. | DESCRIPTION               |
|------|-----|----------|---------------------------|
| 1    | 1   | REF      | WORM 6B-RH-SI             |
| 2    | 1   | REF      | GASKET MTR 2A MAG         |
| 3    | 1   | REF      | RING SNAP SPIRLX #RRN-287 |
| 4    | 2   | REF      | BEARING CONE #LM501349    |
| 5    | 2   | REF      | BEARING CUP LM #501310    |



## ***A40 OUTER BOOM ASSEMBLY 1 HYD. EXTENSION – P/N: 407295000***






***A40 OUTER BOOM ASSEMBLY***  
***1 HYD. EXTENSION – P/N: 407295000***

| ITEM NO. | QTY. | PART NO.  | DESCRIPTION           |
|----------|------|-----------|-----------------------|
| 1        | 1    | 407281000 | OUTER BOOM WDMT       |
| 2        | 4    | 407202000 | PAD BOOM 2.50 O.D.    |
| 3        | 1    | 407285000 | 1ST SECT BOOM WDMT    |
| 4        | 1    | 407064000 | CYL 1st EXTENSION     |
| 5        | 2    | 407221000 | CYL KEEPER            |
| 6        | 2    | 407222000 | CYL KEEPER 1ST SECT   |
| 7        | 8    | 021500    | WASHER SP LK 1/2      |
| 8        | 8    | 011510    | SCW HX 1/2 NC X 1 1/4 |



## ***A40 OUTER BOOM ASSEMBLY 1 HYD. EXTENSIONS 1 MANUAL – P/N: 407296000***






***A40 OUTER BOOM ASSEMBLY***  
***1 HYD. EXTENSIONS 1 MANUAL – P/N: 407296000***

| ITEM NO. | QTY. | PART NO.  | DESCRIPTION              |
|----------|------|-----------|--------------------------|
| 1        | 1    | 407281000 | OUTER BOOM WDMT          |
| 2        | 8    | 407202000 | PAD BOOM 2.50 O.D.       |
| 3        | 1    | 407285000 | 1ST SECT BOOM WDMT       |
| 4        | 1    | 407286000 | 2ND SECT BOOM WDNT       |
| 5        | 1    | 407064000 | CYL 1st EXTENSION        |
| 6        | 2    | 407221000 | CYL KEEPER               |
| 7        | 2    | 407222000 | CYL KEEPER 1ST SECT      |
| 8        | 8    | 021500    | WASHER SP LK 1/2         |
| 9        | 8    | 011510    | SCW HX 1/2 NC X 1 1/4    |
| 10       | 2    | 017102    | NUT HEX 3/8 UNF          |
| 11       | 2    | 008701    | SCW HX 3/8 UNC X 7/8 GR5 |
| 12       | 1    | 373213    | PIN ASSY W/LANYARD       |



## ***A40 OUTER BOOM ASSEMBLY 2 HYD. EXTENSION – P/N: 407280000***





## ***A40 OUTER BOOM ASSEMBLY 2 HYD. EXTENSION – P/N: 407280000***


| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                    |
|----------|------|-----------|--------------------------------|
| 1        | 1    | 407281000 | OUTER BOOM WDMT                |
| 2        | 1    | 407285000 | 1ST SECT BOOM WDMT             |
| 3        | 1    | 407286000 | 2ND SECT BOOM WDNT             |
| 4        | 1    | 407063000 | CYL 2nd EXTENSION              |
| 5        | 1    | 407064000 | CYL 1st EXTENSION              |
| 6        | 2    | 407221000 | CYL KEEPER                     |
| 7        | 2    | 407223000 | CYL KEEPER 1ST SECT 2 CYL'S    |
| 8        | 2    | 407224000 | CYL KEEPER 2ND SECT            |
| 9        | 1    | 407229000 | WEAR PAD MTG BRKT              |
| 10       | 1    | 407284000 | MTG PLATE WDMT DUAL SEQUENCING |
| 11       | 1    | 369701    | DUAL SEQUENCING VALVE BLOCK    |
| 12       | 1    | 407294000 | EXTENSION CYL REST             |
| 13       | 8    | 407202000 | PAD BOOM 2.50 O.D.             |
| 14       | 1    | 480036    | PAD BOOM SIDE                  |
| 15       | 1    | 407316000 | WEAR PAD .31 X 1.50 X 3.00     |
| 16       | 2    | 020901    | WASHER FL 5/16                 |
| 17       | 2    | 016801    | NUT HEX-LOCK 5/16 NC           |
| 18       | 2    | 020600    | WASHER SP LK 5/16 NC           |
| 19       | 2    | 007401    | SCW 5/16-18 X 1/2 LG           |
| 20       | 14   | 021500    | WASHER SP LK 1/2               |
| 21       | 2    | 010201    | SCW HX 1/2 NC x 1 1/2          |
| 22       | 10   | 011510    | SCW HX 1/2 NC X 1 1/4          |
| 23       | 4    | 021200    | WASHER FL 3/8                  |
| 24       | 2    | 811052    | SCW HX 3/8 NC X 5              |
| 25       | 2    | 017301    | NUT HX NYLON LOCK 3/8 NCCP     |
| 26       | 4    | 020200    | WASHER SPLIT LOCK 1/4          |
| 27       | 4    | 005501    | SCW HX 1/4 NF X 3/4            |
| 28       | 3    | 480037    | SHIM SMALL                     |
| 29       | 2    | 010000    | SCW HX 1/2 X 3/4 NC            |



***NOTES***




## ***A40 OUTER BOOM ASSEMBLY 2 HYD. EXTENSIONS 1 MANUAL – P/N: 407297000***





## ***A40 OUTER BOOM ASSEMBLY 2 HYD. EXTENSIONS 1 MANUAL – P/N: 407297000***





## ***A40 OUTER BOOM ASSEMBLY***

### ***2 HYD. EXTENSIONS 1 MANUAL – P/N: 407297000***

| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                    |
|----------|------|-----------|--------------------------------|
| 1        | 1    | 407281000 | OUTER BOOM WDMT                |
| 2        | 1    | 407285000 | 1ST SECT BOOM WDMT             |
| 3        | 1    | 407286000 | 2ND SECT BOOM WDNT             |
| 4        | 1    | 407271000 | 3RD SECT BOOM WDMT             |
| 5        | 1    | 407063000 | CYL 2nd EXTENSION              |
| 6        | 1    | 407064000 | CYL 1st EXTENSION              |
| 7        | 2    | 407221000 | CYL KEEPER                     |
| 8        | 2    | 407223000 | CYL KEEPER 1ST SECT 2 CYL'S    |
| 9        | 2    | 407224000 | CYL KEEPER 2ND SECT            |
| 10       | 1    | 407229000 | WEAR PAD MTG BRKT              |
| 11       | 1    | 407284000 | MTG PLATE WDMT DUAL SEQUENCING |
| 12       | 1    | 369701    | DUAL SEQUENCING VALVE BLOCK    |
| 13       | 1    | 407294000 | EXTENSION CYL REST             |
| 14       | 8    | 407202000 | PAD BOOM 2.50 O.D.             |
| 15       | 4    | 407277000 | PAD BOOM 1.5 O.D.              |
| 16       | 3    | 480037    | SHIM SMALL                     |
| 17       | 1    | 480036    | PAD BOOM SIDE                  |
| 18       | 1    | 407316000 | WEAR PAD .31 X 1.50 X 3.00     |
| 19       | 2    | 017102    | NUT HEX 3/8 UNF                |
| 20       | 2    | 008701    | SCW HX 3/8 UNC X 7/8 GR5       |
| 21       | 2    | 020901    | WASHER FL 5/16                 |
| 22       | 2    | 016801    | NUT HEX-LOCK 5/16 NC           |
| 23       | 2    | 020600    | WASHER SP LK 5/16 NC           |
| 24       | 2    | 007401    | SCW 5/16-18 X 1/2 LG           |
| 25       | 4    | 021200    | WASHER FL 3/8                  |
| 26       | 2    | 811052    | SCW HX 3/8 NC X 5              |
| 27       | 2    | 017301    | NUT HX NYLON LOCK 3/8 NCCP     |
| 28       | 4    | 020200    | WASHER SPLIT LOCK 1/4          |
| 29       | 4    | 005501    | SCW HX 1/4 NF X 3/4            |
| 30       | 1    | 372168    | PIN ASSY W/LANYARD             |
| 31       | 14   | 021500    | WASHER SP LK 1/2               |
| 32       | 2    | 010201    | SCW HX 1/2 NC x 1 1/2          |
| 33       | 10   | 011510    | SCW HX 1/2 NC X 1 1/4          |
| 34       | 2    | 010000    | SCW HX 1/2 X 3/4 NC            |




***NOTES***



## ***A40 HYDRAULIC SCHEMATIC - P/N: 407061000***

### ***5 FUNCTION CONTROL VALVE 1 HYD EXTENSION***




| A40 HYD SYSTEM INFO |                            |
|---------------------|----------------------------|
| HYD PUMP =          | 8 GPM                      |
| HYD RESERVOIR =     | 12 GAL CAPACITY            |
| SYSTEM PRESS =      | 3800 PSI MAX               |
| EXTENSION =         | EXT 2000 PSI, RET 2500 PSI |
| OUTER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| INNER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| ROTATION =          | EXT 1125 PSI, RET 1125 PSI |



## **A40 HYDRAULIC SCHEMATIC - P/N: 407061000**

### **5 FUNCTION CONTROL VALVE 1 HYD EXTENSION**





***A40 HYDRAULIC SCHEMATIC - P/N: 407061000***  
***5 FUNCTION CONTROL VALVE 1 HYD EXTENSION***

|   | ITEM | QTY | PART NO   | DESCRIPTION                           |
|---|------|-----|-----------|---------------------------------------|
|   | 1    | 2   | 407050000 | OUTRIGGER CYL W/MANUAL VALVE          |
|   | 2    | 1   | 407051000 | INNER BOOM CYLINDER                   |
|   | 3    | 1   | 407052000 | OUTER BOOM CYLINDER                   |
|   | 4    | 1   | 407064000 | EXTENSION CYLINDER                    |
|   | 5    | 1   | 407055000 | MANUAL CONTROL VALVE (5) FUNCTION     |
|   | 6    | 1   | 372044000 | FITTING 90 DEG -10SAE/-8JIC           |
|   | 7    | 1   | 367210000 | FITTING STR -16 SAE/-12 JIC           |
|   | 7    | 1   | 367283000 | FITTING 90 DEG -12 JIC                |
|   | 8    | 1   | 407109000 | HYDRAULIC MOTOR 10.0 CU IN            |
|   | 9    | 4   | 241175000 | FITTING 90 DEG -6 SAE/-6 JIC          |
|   | 10   | 5   | 330645000 | FITTING 90 DEG -6 SAE/-6 JIC LONG     |
|   | 11   | 2   | 812209195 | HOSE ASSY -6 X 195 LG STR             |
|   | 12   | 1   | 362020000 | FITTING 90 DEG -8 SAE/-8 JIC          |
|   | 13   | 10  | 200876000 | FITTING STR -6 SAE/-6 JIC             |
|   | 14   | 1   | 812303024 | HOSE ASSY -8 X 24 STR                 |
|   | 15   | 1   | 812203024 | HOSE ASSY -6 X 24 STR                 |
|   | 16   | 1   | 812203175 | HOSE ASSY -6 X 165 STR                |
|   | 17   | 1   | 812203050 | HOSE ASSY -6 X 50 STR                 |
|   | 18   | 2   | 812203110 | HOSE ASSY -6 X 110 STR                |
|   | 19   | 1   | 407062000 | FITTING 90 DEG -6 SAE/-8 JIC          |
|   | 20   | 2   | 812203126 | HOSE ASSY -6 X 126 STR                |
|   | 21   | 1   | 490198000 | FITTING 90 DEG -10 SAE/-6 JIC         |
|   | 22   | 1   | 360445000 | CAP -8 JIC                            |
|   | 23   | 1   | 369219000 | FITTING TEE -8 SAE/-8 JIC RUN         |
|   | 24   | 1   | 812514060 | HOSE ASSY -12/-8 X 60 STR             |
|   | 25   | 1   | 812303136 | HOSE ASSY -6 X 136 STR                |
|   |      |     |           |                                       |
| * | 26   | REF | 407050001 | SEAL KIT OUTRIGGER CYL W/MANUAL VALVE |
| * | 27   | REF | 407051001 | SEAL KIT INNER BOOM CYLINDER          |
| * | 28   | REF | 407052001 | SEAL KIT OUTER BOOM CYLINDER          |
| * | 29   | REF | 407063001 | SEAL KIT EXTENSION CYLINDER           |




***NOTES***



## ***A40 HYDRAULIC SCHEMATIC - P/N: 407061002***

### ***5 FUNCTION CONTROL VALVE 2 HYD EXTENSION***




| A40 HYD SYSTEM INFO |                            |
|---------------------|----------------------------|
| HYD PUMP =          | 8 GPM                      |
| HYD RESERVOIR =     | 12 GAL CAPACITY            |
| SYSTEM PRESS =      | 3800 PSI MAX               |
| EXTENSION =         | EXT 2000 PSI, RET 2500 PSI |
| OUTER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| INNER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| ROTATION =          | EXT 1125 PSI, RET 1125 PSI |



## **A40 HYDRAULIC SCHEMATIC - P/N: 407061002**

### **5 FUNCTION CONTROL VALVE 2 HYD EXTENSION**



**NOTE:**

1. \* ARE NOT SHOWN
2. THE ROTATION MOTOR IS STAMPED "A" & "B".
3. THE COUNTER BALANCE BLOCK PORTS ARE MARKED "EXT" & "RET".
4. THE COUNTERBALANCE BLOCKS ALSO HAVE (2) TEST PORTS.
5. + ITEMS ARE SUPPLIED WITH ITEM-5, MANUAL CONTROL VALVE.
6. TO SET SYSTEM PRESSURE, CONNECT GAUGE TO ITEM-22 (TEE) LOCATED @ VALVE "P" PORT



***A40 HYDRAULIC SCHEMATIC - P/N: 407061002***  
***5 FUNCTION CONTROL VALVE 2 HYD EXTENSION***

|   | ITEM | QTY | PART NO   | DESCRIPTION                           |
|---|------|-----|-----------|---------------------------------------|
|   | 1    | 2   | 407050000 | OUTRIGGER CYL W/MANUAL VALVE          |
|   | 2    | 1   | 407051000 | INNER BOOM CYLINDER                   |
|   | 3    | 1   | 407052000 | OUTER BOOM CYLINDER                   |
|   | 4    | 1   | 407064000 | EXTENSION CYLINDER                    |
|   | 4.1  | 1   | 407063000 | EXTENSION CYLINDER 2nd EXT            |
|   | 5    | 1   | 407055000 | MANUAL CONTROL VALVE (5) FUNCTION     |
|   | 6    | 1   | 372044000 | FITTING 90 DEG -10SAE/-8JIC           |
|   | 7    | 1   | 367210000 | FITTING STR -16 SAE/-12 JIC           |
|   | 7    | 1   | 367283000 | FITTING 90 DEG -12 JIC                |
|   | 8    | 1   | 407109000 | HYDRAULIC MOTOR 10.0 CU IN            |
|   | 9    | 4   | 241175000 | FITTING 90 DEG -6 SAE/-6 JIC          |
|   | 10   | 5   | 330645000 | FITTING 90 DEG -6 SAE/-6 JIC LONG     |
|   | 11   | 2   | 812209195 | HOSE ASSY-6 X 195 LG STR              |
|   | 12   | 1   | 362020000 | FITTING 90 DEG -8 SAE/-8 JIC          |
|   | 13   | 10  | 200876000 | FITTING STR -6 SAE/-6 JIC             |
|   | 14   | 1   | 812303024 | HOSE ASSY-8 X 24 STR                  |
|   | 15   | 1   | 812203024 | HOSE ASSY-6 X 24 STR                  |
|   | 16   | 1   | 812203175 | HOSE ASSY-6 X 165 STR                 |
|   | 17   | 1   | 812203050 | HOSE ASSY-6 X 50 STR                  |
|   | 18   | 2   | 812203110 | HOSE ASSY-6 X 110 STR                 |
|   | 19   | 1   | 407062000 | FITTING 90 DEG -6 SAE/-8 JIC          |
|   | 20   | 2   | 812203126 | HOSE ASSY-6 X 126 STR                 |
|   | 21   | 1   | 490198000 | FITTING 90 DEG -10 SAE/-6 JIC         |
|   | 22   | 1   | 360445000 | CAP -8 JIC                            |
|   | 23   | 1   | 369219000 | FITTING TEE -8 SAE/-8 JIC RUN         |
|   | 24   | 1   | 812514060 | HOSE ASSY-12/-8 X 60 STR              |
|   | 25   | 1   | 369701000 | VALVE DUAL SEQUENCE                   |
|   | 26   | 6   | 202755000 | FITTING STR 10 SAE/-6 JIC             |
|   | 27   | 2   | 812209112 | HOSE ASSY-6/-6 90 DEG X 112           |
|   | 28   | 2   | 812206025 | HOSE ASSY-6/-6 90 DEG LG X 25         |
|   | 29   | 4   | 241175000 | FITTING 90 DEG -6 SAE/-6 JIC SHORT    |
|   | 30   | 1   | 812203136 | HOSE ASSY-6/-6 LG X 136               |
|   |      |     |           |                                       |
| * | 31   | REF | 407050001 | SEAL KIT OUTRIGGER CYL W/MANUAL VALVE |
| * | 32   | REF | 407051001 | SEAL KIT INNER BOOM CYLINDER          |
| * | 33   | REF | 407052001 | SEAL KIT OUTER BOOM CYLINDER          |
| * | 34   | REF | 407063001 | SEAL KIT EXTENSION CYLINDER           |




***NOTES***



## ***A40 HYDRAULIC SCHEMATIC - P/N: 407061001***

### ***7 FUNCTION CONTROL VALVE 1 HYD EXTENSION***




| A40 HYD SYSTEM INFO |                            |
|---------------------|----------------------------|
| HYD PUMP =          | 8 GPM                      |
| HYD RESERVOIR =     | 12 GAL CAPACITY            |
| SYSTEM PRESS =      | 3800 PSI MAX               |
| EXTENSION =         | EXT 2000 PSI, RET 2500 PSI |
| OUTER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| INNER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| ROTATION =          | EXT 1125 PSI, RET 1125 PSI |



## **A40 HYDRAULIC SCHEMATIC - P/N: 407061001**

### **7 FUNCTION CONTROL VALVE 1 HYD EXTENSION**





***A40 HYDRAULIC SCHEMATIC - P/N: 407061001  
7 FUNCTION CONTROL VALVE 1 HYD EXTENSION***


|   | ITEM | QTY | PART NO   | DESCRIPTION                           |
|---|------|-----|-----------|---------------------------------------|
|   | 1    | 2   | 407050000 | OUTRIGGER CYL W/MANUAL VALVE          |
|   | 2    | 1   | 407051000 | INNER BOOM CYLINDER                   |
|   | 3    | 1   | 407052000 | OUTER BOOM CYLINDER                   |
|   | 4    | 1   | 407064000 | EXTENSION CYLINDER                    |
|   | 5    | 1   | 407056000 | MANUAL CONTROL VALVE (5) FUNCTION     |
|   | 6    | 1   | 372044000 | FITTING 90 DEG -10SAE/-8JIC           |
|   | 7    | 1   | 367210000 | FITTING STR -16 SAE/-12 JIC           |
|   | 7    | 1   | 367283000 | FITTING 90 DEG -12 JIC                |
|   | 8    | 1   | 407109000 | HYDRAULIC MOTOR 10.0 CU IN            |
|   | 9    | 4   | 241175000 | FITTING 90 DEG -6 SAE/-6 JIC          |
|   | 10   | 5   | 330645000 | FITTING 90 DEG -6 SAE/-6 JIC LONG     |
|   | 11   | 2   | 812209195 | HOSE ASSY -6 X 195 LG STR             |
|   | 12   | 1   | 362020000 | FITTING 90 DEG -8 SAE/-8 JIC          |
|   | 13   | 10  | 200876000 | FITTING STR -6 SAE/-6 JIC             |
|   | 14   | 1   | 812303024 | HOSE ASSY -8 X 24 STR                 |
|   | 15   | 1   | 812203024 | HOSE ASSY -6 X 24 STR                 |
|   | 16   | 1   | 812203175 | HOSE ASSY -6 X 165 STR                |
|   | 17   | 1   | 812203050 | HOSE ASSY -6 X 50 STR                 |
|   | 18   | 2   | 812203110 | HOSE ASSY -6 X 110 STR                |
|   | 19   | 1   | 407062000 | FITTING 90 DEG -6 SAE/-8 JIC          |
|   | 20   | 2   | 812203126 | HOSE ASSY -6 X 126 STR                |
|   | 21   | 1   | 490198000 | FITTING 90 DEG -10 SAE/-6 JIC         |
|   | 22   | 1   | 360445000 | CAP -8 JIC                            |
|   | 23   | 1   | 369219000 | FITTING TEE -8 SAE/-8 JIC RUN         |
|   | 24   | 1   | 812514060 | HOSE ASSY -12/-8 X 60 STR             |
|   | 25   | 1   | 812303136 | HOSE ASSY -6 X 136 STR                |
|   |      |     |           |                                       |
| * | 26   | REF | 407050001 | SEAL KIT OUTRIGGER CYL W/MANUAL VALVE |
| * | 27   | REF | 407051001 | SEAL KIT INNER BOOM CYLINDER          |
| * | 28   | REF | 407052001 | SEAL KIT OUTER BOOM CYLINDER          |
| * | 29   | REF | 407063001 | SEAL KIT EXTENSION CYLINDER           |



***NOTES***



## A40 HYDRAULIC SCHEMATIC - P/N: 407061003 7 FUNCTION CONTROL VALVE 2 HYD EXTENSION




| A40 HYD SYSTEM INFO |                            |
|---------------------|----------------------------|
| HYD PUMP =          | 8 GPM                      |
| HYD RESERVOIR =     | 12 GAL CAPACITY            |
| SYSTEM PRESS =      | 3800 PSI MAX               |
| EXTENSION =         | EXT 2000 PSI, RET 2500 PSI |
| OUTER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| INNER BOOM =        | EXT 3500 PSI, RET 2000 PSI |
| ROTATION =          | EXT 1125 PSI, RET 1125 PSI |



## **A40 HYDRAULIC SCHEMATIC - P/N: 407061003**

### **7 FUNCTION CONTROL VALVE 2 HYD EXTENSION**



**NOTE:**

1. \* ARE NOT SHOWN
2. THE ROTATION MOTOR IS STAMPED "A" & "B".
3. THE COUNTER BALANCE BLOCK PORTS ARE MARKED "EXT" & "RET".
4. THE COUNTERBALANCE BLOCKS ALSO HAVE (2) TEST PORTS.
5. + ITEMS ARE SUPPLIED WITH ITEM-5, MANUAL CONTROL VALVE.
6. TO SET SYSTEM PRESSURE, CONNECT GAUGE TO ITEM-22 (TEE) LOCATED @ VALVE "P" PORT




***A40 HYDRAULIC SCHEMATIC - P/N: 407061003***  
***7 FUNCTION CONTROL VALVE 2 HYD EXTENSION***

|   | ITEM | QTY | PART NO   | DESCRIPTION                           |
|---|------|-----|-----------|---------------------------------------|
|   | 1    | 2   | 407050000 | OUTRIGGER CYL W/MANUAL VALVE          |
|   | 2    | 1   | 407051000 | INNER BOOM CYLINDER                   |
|   | 3    | 1   | 407052000 | OUTER BOOM CYLINDER                   |
|   | 4    | 1   | 407064000 | EXTENSION CYLINDER                    |
|   | 4.1  | 1   | 407063000 | EXTENSION CYLINDER 2nd EXT            |
|   | 5    | 1   | 407056000 | MANUAL CONTROL VALVE (7) FUNCTION     |
|   | 6    | 1   | 372044000 | FITTING 90 DEG -10SAE/-8JIC           |
|   | 7    | 1   | 367210000 | FITTING STR -16 SAE/-12 JIC           |
|   | 7    | 1   | 367283000 | FITTING 90 DEG -12 JIC                |
|   | 8    | 1   | 407109000 | HYDRAULIC MOTOR 10.0 CU IN            |
|   | 9    | 4   | 241175000 | FITTING 90 DEG -6 SAE/-6 JIC          |
|   | 10   | 5   | 330645000 | FITTING 90 DEG -6 SAE/-6 JIC LONG     |
|   | 11   | 2   | 812209195 | HOSE ASSY-6 X 195 LG STR              |
|   | 12   | 1   | 362020000 | FITTING 90 DEG -8 SAE/-8 JIC          |
|   | 13   | 10  | 200876000 | FITTING STR -6 SAE/-6 JIC             |
|   | 14   | 1   | 812303024 | HOSE ASSY-8 X 24 STR                  |
|   | 15   | 1   | 812203024 | HOSE ASSY-6 X 24 STR                  |
|   | 16   | 1   | 812203175 | HOSE ASSY-6 X 165 STR                 |
|   | 17   | 1   | 812203050 | HOSE ASSY-6 X 50 STR                  |
|   | 18   | 2   | 812203110 | HOSE ASSY-6 X 110 STR                 |
|   | 19   | 1   | 407062000 | FITTING 90 DEG -6 SAE/-8 JIC          |
|   | 20   | 2   | 812203126 | HOSE ASSY-6 X 126 STR                 |
|   | 21   | 1   | 490198000 | FITTING 90 DEG -10 SAE/-6 JIC         |
|   | 22   | 1   | 360445000 | CAP -8 JIC                            |
|   | 23   | 1   | 369219000 | FITTING TEE -8 SAE/-8 JIC RUN         |
|   | 24   | 1   | 812514060 | HOSE ASSY-12/-8 X 60 STR              |
|   | 25   | 1   | 369701000 | VALVE DUAL SEQUENCE                   |
|   | 26   | 6   | 202755000 | FITTING STR 10 SAE/-6 JIC             |
|   | 27   | 2   | 812209112 | HOSE ASSY-6/-6 90 DEG X 112           |
|   | 28   | 2   | 812206025 | HOSE ASSY-6/-6 90 DEG LG X 25         |
|   | 29   | 4   | 241175000 | FITTING 90 DEG -6 SAE/-6 JIC SHORT    |
|   | 30   | 1   | 812203136 | HOSE ASSY-6/-6 LG X 136               |
|   |      |     |           |                                       |
| * | 31   | REF | 407050001 | SEAL KIT OUTRIGGER CYL W/MANUAL VALVE |
| * | 32   | REF | 407051001 | SEAL KIT INNER BOOM CYLINDER          |
| * | 33   | REF | 407052001 | SEAL KIT OUTER BOOM CYLINDER          |
| * | 34   | REF | 407063001 | SEAL KIT EXTENSION CYLINDER           |



## ***CONTROL VALVE ASSY - 5 FUNCTION***

***P/N: 407078000***




### **VALVE SUPPLIED WITH FITTINGS (NOT SHOWN)**

| ITEM NO | QTY | PART NO   | DESCRIPTION                     |
|---------|-----|-----------|---------------------------------|
| 1       | 1   | 407055000 | VALVE CONTROL MANUAL 5 SECTION  |
| 2       | 4   | 407057000 | LEVER BOX REMOTE CABLE OPERATOR |
| 3       | 4   | 407060000 | CONNECTOR KIT REMOTE OPERATOR   |
| 4       | 4   | 407059000 | CONNECTOR KIT DIRECTIONAL VALVE |
| 5       | 4   | 407058000 | CABLE REMOTE 59" LG             |
| 6       | 4   | 407080000 | LEVER M8 X 200mm                |
| 7       | 1   | 407081000 | LEVER M8 X 150mm                |
| 8       | 4   | 407082000 | LEVER M10 X 200mm               |



## ***CONTROL VALVE ASSY - 7 FUNCTION***

***P/N: 407079000***



VALVE SUPPLIED WITH FITTINGS (NOT SHOWN)


| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                     |
|----------|------|-----------|---------------------------------|
| 1        | 1    | 407056000 | VALVE CONTROL MANUAL 7 SECTION  |
| 2        | 6    | 407057000 | LEVER BOX REMOTE CABLE OPERATOR |
| 3        | 6    | 407060000 | CONNECTOR KIT REMOTE OPERATOR   |
| 4        | 6    | 407059000 | CONNECTOR KIT DIRECTIONAL VALVE |
| 5        | 6    | 407058000 | CABLE REMOTE 59" LG             |
| 6        | 6    | 407080000 | LEVER M8 X 200mm                |
| 7        | 1    | 407081000 | LEVER M8 X 150mm                |
| 8        | 6    | 407082000 | LEVER M10 X 200mm               |



***NOTES***



***DUAL SEQUENCING VALVE***  
***P/N: 369701000***



| ITEM | QTY | PART NO   | DESCRIPTION                 |
|------|-----|-----------|-----------------------------|
| 1    | 1   | 369701    | DUAL SEQUENCING VALVE BLOCK |
| 2    | 2   | 369701002 | CHECK VALVE                 |
| 3    | 2   | 369701001 | SEQUENCING CARTRIDGE        |



## ***DUAL SEQUENCING VALVE ADJUSTMENT***

### ***P/N: 369701000***


The (2) Extension Cylinders should be phased so that the first boom section goes out first followed by the second boom section and vice a verse on retraction. If the cylinders do not sequence properly, the following procedure may be used to correct the sequencing.

1. Loosen both cartridge jam nuts (CCW) and back off (CCW) one turn the cartridge pressure adjustment screws. See Figure 01?
2. Collapse both Extension Cylinders.
3. Start extending the Extension Cylinders and slowing turn-in (CW) the Extend Cartridge Pressure Adjustment Screw until the 2<sup>nd</sup> Extension Cylinder stops moving. See Figure 01?
4. Collapse both Extension Cylinders and extend fully. If Extension Cylinders do not correctly sequence, repeat step 3.
5. With both Extension Cylinders fully extended, start retracting the Extension Cylinders and slowing turn-in (CW) the Retract Cartridge Pressure Adjustment Screw until the 1<sup>st</sup> Extension Cylinder stops moving. See Figure 01?
6. Extend both Extension Cylinders and retract fully. If Extension Cylinders do not correctly sequence, repeat step 5.
7. Turn-in each Pressure Adjustment Screw 1/8 turn and operate Extension Cylinders fully each direction to be sure they sequence correctly.
8. Tighten both cartridge jams nuts (CW).



## ***DUAL SEQUENCING VALVE ADJUSTMENT***

***P/N: 369701000***



**VIEW SHOWS BOOM SECTIONS IN THE STOWED POSITION.**




***NOTES***



## ***A40 HYDRAULIC TANK ASSEMBLY***

### ***P/N: 407065000***




| <u>ITEM NO.</u> | <u>QTY.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u>               |
|-----------------|-------------|-----------------|----------------------------------|
| 1               | 1           | 407070000       | HYD TANK WDMT 12 GAL             |
| 2               | 1           | 407067000       | FLUID LEVEL W/TEMP INDICATOR     |
| 3               | 1           | 407066000       | IN-TANK FILTER W/FILLER BREATHER |
| 4               | 1           | 750477000       | PLUG PIPE -8 NPTF                |
| 5               | 1           | 360282000       | STRAINER SUCTION                 |
| 6               | 1           | 407076000       | PLATE FILTER MOUNT               |
| 7               | 2           | 017300000       | NUT HX 3/8 NC                    |
| 8               | 6           | 021100000       | WASHER SPLK 3/8                  |
| 9               | 6           | 008400000       | SCW HEX HD 3/8-16 UNC X 3/4 GR 5 |



## ***A40 DECAL ASSEMBLY – 5 FUNCTION***

### ***P/N: 407020000***






***A40 DECAL ASSEMBLY – 5 FUNCTION***  
***P/N: 407020000***

| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                          |
|----------|------|-----------|--------------------------------------|
| 1        | 2    | 367242    | DECAL ARROW BLACK 2 INCH             |
| 2        | 2    | 759017    | DECAL DANGER MOVING OUTRIGGER        |
| 3        | 2    | 040519    | DECAL DANGER SCISSOR POINT           |
| 4        | 2    | 040581    | DECAL DANGER SERIOUS CRUSHING INJURY |
| 5        | 2    | 367241    | DECAL DANGER "ELECTROCUTION HAZARD"  |
| 6        | 1    | 367250    | DECAL DANGER "STOWING & UNFOLDING"   |
| 7        | 2    | 725961    | DECAL DANGER "OUTRIGGERS"            |
| 8        | 1    | 367244    | DECAL DANGER "HYDRAULIC FLUID LEVEL" |
| 9        | 4    | 367251    | DECAL DANGER "STAY CLEAR OF BOOM"    |
| 10       | 2    | 407021000 | DECAL A40 LOGO                       |
| 11       | 2    | 407022000 | DECAL LOAD CHART A40                 |
| 12       | 2    | 407023000 | DECAL DANGER ONE PIECE               |
| 13       | 1    | 407024000 | DECAL CONTROL VALVE                  |
| 14       | 1    | 407026000 | DECAL CONTROL VALVE REMOTE OPER      |
| 15       | 1    | 040630    | DECAL DANGER "STAY CLEAR OF LOAD"    |
| 16       | 2    | 366389    | DECAL AUTO CRANE                     |
| 17       | 3    | 360034    | DECAL AUTO CRANE LOGO                |
| 18       | 1    | 367243    | DECAL "GREASE"                       |



## A40 DECAL ASSEMBLY – 7 FUNCTION

P/N: 407025000





***A40 DECAL ASSEMBLY – 7 FUNCTION***  
***P/N: 407025000***


| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                          |
|----------|------|-----------|--------------------------------------|
| 1        | 2    | 367242    | DECAL ARROW BLACK 2 INCH             |
| 2        | 2    | 759017    | DECAL DANGER MOVING OUTRIGGER        |
| 3        | 2    | 040519    | DECAL DANGER SCISSOR POINT           |
| 4        | 2    | 040581    | DECAL DANGER SERIOUS CRUSHING INJURY |
| 5        | 2    | 367241    | DECAL DANGER "ELECTROCUTION HAZARD"  |
| 6        | 1    | 367250    | DECAL DANGER "STOWING & UNFOLDING"   |
| 7        | 2    | 725961    | DECAL DANGER "OUTRIGGERS"            |
| 8        | 1    | 367244    | DECAL DANGER "HYDRAULIC FLUID LEVEL" |
| 9        | 4    | 367251    | DECAL DANGER "STAY CLEAR OF BOOM"    |
| 10       | 2    | 407021000 | DECAL A40 LOGO                       |
| 11       | 2    | 407022000 | DECAL LOAD CHART A40                 |
| 12       | 2    | 407023000 | DECAL DANGER ONE PIECE               |
| 13       | 1    | 407024000 | DECAL CONTROL VALVE                  |
| 14       | 1    | 407026000 | DECAL CONTROL VALVE REMOTE OPER      |
| 15       | 1    | 040630    | DECAL DANGER "STAY CLEAR OF LOAD"    |
| 16       | 2    | 366389    | DECAL AUTO CRANE                     |
| 17       | 3    | 360034    | DECAL AUTO CRANE LOGO                |
| 18       | 1    | 367243    | DECAL "GREASE"                       |
| 19       | 2    | 407027000 | DECAL AUX FUNCTION                   |




## ***SAFETY DECAL SECTION***

### ***A40 SERIES***


PART NO.: 040581000  
DECAL: STAND CLEAR  
FUNCTION: To inform the operator of danger associated with outriggers.  
QUANTITY: 2  
PLACEMENT: On outrigger cylinder



PART NO.: 040630000  
DECAL: STAY CLEAR OF LOAD  
FUNCTION: To inform the operator of hazard of proximity of contact with the crane load during operation.  
QUANTITY: 1  
PLACEMENT: On lifting hook



PART NO.: 367244000  
DECAL: HYDRAULIC FLUID  
FUNCTION: To inform the operator to check fluid level and check for leaks/damage.  
QUANTITY: 1  
PLACEMENT: Hydraulic reservoir







## ***SAFETY DECAL SECTION***

### ***A40 SERIES***

PART NO.: 367250000  
DECAL: STOWING & UNFOLDING  
FUNCTION: To inform the operator of the danger a moving boom will cause.  
QUANTITY: 1  
PLACEMENT: Back of pedestal



PART NO.: 367251000  
DECAL: STAY CLEAR OF BOOM  
FUNCTION: To inform the operator of hazard of proximity or contact with the crane boom operation.  
QUANTITY: 4  
PLACEMENT: End of booms







## ***SAFETY DECAL SECTION***

### ***A40 SERIES***

PART NO.: 725961000  
DECAL: OUTRIGGERS  
FUNCTION: To inform the operator that the outriggers must be extended and pinned in place before operating the crane.  
QUANTITY: 2  
PLACEMENT: Both sides of crane base



PART NO.: 759017000  
DECAL: MOVING OUTRIGGER  
FUNCTION: To inform the operator of the hazard involved while operating outriggers.  
QUANTITY: 2  
PLACEMENT: On outrigger cylinder





## ***SAFETY DECAL SECTION***

### ***A40 SERIES***


PART NO.: 367241000

DECAL: ELECTROCUTION HAZARD

QUANTITY: 2

FUNCTION: To inform the operator of the hazard involved with contacting electrical power lines with crane boom.

PLACEMENT: Both sides of boom




PART NO.: 040519000

DECAL: SCISSORS POINT

QUANTITY: 2

FUNCTION: To inform the operator of possible danger at scissors point on crane.

PLACEMENT: Both sides of the lift cylinder





## SAFETY DECAL SECTION

### A40 SERIES

PART NO.: 407023000

DECAL: DANGER ONE PIECE

QUANTITY: 1


FUNCTION: To inform the operator of the dangers and hazards involved in the operation of crane.

PLACEMENT: On crane base

**⚠ DANGER**

**ELECTROCUTION HAZARD**  
THIS CRANE IS NOT INSULATED  
**DEATH OR SERIOUS INJURY**  
WILL RESULT FROM CONTACT  
OR INADEQUATE CLEARANCE

Maintain safe clearance from electrical lines. Allow for boom, electrical line, and load line swaying. This crane does not provide protection from contact with or proximity to an electrically charged conductor. Maintain a clearance of at least 10 feet between any part of the crane, load line, or load and any electrical line carrying up to 50,000 volts (50 kV). If electrical line voltage is unknown, assume maximum voltage and maintain a clearance of at least 45 feet.




| NOMINAL VOLTAGE, kV<br>(Phase to Phase) | MINIMUM REQUIRED<br>DISTANCE |
|-----------------------------------------|------------------------------|
| TO 50                                   | 10 feet                      |
| OVER 50 TO 200                          | 15 feet                      |
| OVER 200 TO 350                         | 20 feet                      |
| OVER 350 TO 500                         | 25 feet                      |
| OVER 500 TO 750                         | 35 feet                      |
| OVER 750 TO 1000                        | 45 feet                      |

**FAILURE TO OBEY THE FOLLOWING WILL RESULT IN  
DEATH OR SERIOUS INJURY**

- DO NOT operate this crane unless you:
  - Have been trained in the safe operation of this crane.
  - Read, understand and follow the safety and operating recommendations contained in the crane manufacturer's manual(s), your employer's work rules, applicable government regulations and industry standards.
  - Read, understand and follow all signs and are sure that all guards, safety signs and other safety features are in place and in proper condition.
  - Read, understand and follow the crane load and work area charts.
- DO NOT operate the crane with personnel under boom or load.
- DO NOT hoist personnel on boom, hook or any device attached to crane boom or load line.
- DO NOT exceed winch or crane ratings. deduct weights of accessories attached to the boom or load line from the load chart or add them to the load weight.
- DO NOT exceed manual boom extension or jib load rating at reduced boom lengths.
- DO NOT side load or drag loads. Keep load under boom tip. Avoid free-swinging loads.
- DO NOT modify or alter this crane without written manufacturer's approval. Use only manufacturer approved attachments or parts on this crane.
- Crane must be mounted on a minimum of the factory recommended chassis. If remounted or rebuilt, the crane and its mounting must be re-certified by a qualified person.
- Inspect the crane and its operation daily.
- Crane must be level. Use only on solid, level surface with the outriggers properly extended for crane stability.
- Reduce loads to allow for factors such as wind, ground conditions, operating speeds and the effect of the suspended loads.
- Stow boom, outriggers, etc. for travel or transport.
- Keep at least 3 wraps of load line on the winch drum as applicable.
- Follow all recommended inspections and maintenance practices listed in the crane manufacturer's manual(s). If manual(s) is missing from this crane, contact the manufacturer for a replacement.

**⚠ DANGER**



**A MOVING BOOM  
WILL CAUSE  
DEATH OR SERIOUS INJURY**

- Stand on the side opposite the boom when folding or stowing the crane.
- Stay clear of the boom when operating or servicing the crane.



**TWO BLOCKING THE CRANE WILL CAUSE  
DEATH, SERIOUS INJURY, OR PROPERTY  
DAMAGE.**

Do not allow the hook block to contact the boom tip by hoisting up, extending, or lowering the boom.

407023000 Rev B

11-9.0.0

4/23/2003



## ***A40 TROUBLESHOOTING***



**CAUTION:** Never check for hydraulic leaks by feeling around hoses, fittings, or any other components. High pressure oil can be injected through the skin causing severe injury, or death.

| PROBLEM                           | POSSIBLE CAUSE                                            | POSSIBLE SOLUTION                                                                                                            |
|-----------------------------------|-----------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| Crane won't move                  | Load too heavy                                            | Check load chart.                                                                                                            |
|                                   | PTO not engaged                                           | Engage PTO.                                                                                                                  |
|                                   | Low fluid level                                           | Check and fill as required.                                                                                                  |
|                                   | Suction line blocked                                      | Remove hose and clear blockage.                                                                                              |
|                                   | Pressure line blocked                                     | Remove hose and clear blockage.                                                                                              |
|                                   | Bad pump                                                  | Check flow and pressure to crane.<br>Note: A bad pump will have some flow but the flow will drop off as pressure increases.  |
| Poor crane performance            | Main relief valve setting too low or not working properly | Check and adjust.                                                                                                            |
|                                   | Pump speed                                                | Check PTO ratio, pump size, and engine speed for proper oil flow. Check oil flow with flow meter installed in pressure line. |
|                                   | Low fluid level                                           | Check and fill.                                                                                                              |
|                                   | Main relief valve setting                                 | Check and adjust.                                                                                                            |
|                                   | Worn pump, motor, or cylinder                             | Replace bad part.                                                                                                            |
|                                   | Blocked filters                                           | Check suction and return filters.                                                                                            |
|                                   | Hydraulic oil temperature too cold                        | Circulate oil to warm.                                                                                                       |
|                                   | Pressure or suction lines blocked                         | Check lines, clean and repair.                                                                                               |
| Noise                             | Load too heavy                                            | Check load chart.                                                                                                            |
|                                   | Pump area                                                 | Circulate oil to warm, check suction line, fill reservoir.                                                                   |
|                                   | Cylinders                                                 | Check for damage to cylinders.                                                                                               |
| Cylinder drift                    | Rotation                                                  | Check rotation bearing, lubricate bearing.                                                                                   |
|                                   | Overload                                                  | Remove overload                                                                                                              |
|                                   | Holding valve relief set too low                          | Replace as required.                                                                                                         |
|                                   | Damaged cylinder                                          | Repair.                                                                                                                      |
|                                   | Dirt in holding or check valve                            | Cycle under no load to reset, clean and/or replace.                                                                          |
|                                   | Air in hydraulic system or entrapped in cylinder          | Cycle cylinder to remove air.                                                                                                |
| Rotation Worm Drive Gear to Hot   | Not enough lubricant                                      | Lubricate as required                                                                                                        |
| Rotation Worm Drive Gear to Noisy | Not enough lubricant                                      | Lubricate as required                                                                                                        |




## ***OVERLOAD WARNING HORN KIT OPTION***

***P/N: 407012000***



CURB SIDE VIEW

**OVERLOAD WARNING HORN KIT OPTION**  
**P/N: 407012000**




| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                   |
|----------|------|-----------|-------------------------------|
| 2        | 1    | 750733    | BACKUP SAFETY ALARM           |
| 3        | 2    | 020400    | WASHER FL SAE 1/4             |
| 4        | 2    | 005604    | SCW HX 1/4 NC X 1             |
| 5        | 2    | 020200    | WASHER SPLIT LOCK 1/4         |
| 6        | 2    | 015900    | NUT 1/4 NC                    |
| 7        | 1    | 407298000 | LOAD SENSOR SWITCH ADJUSTABLE |
| 8        | 1    | 407299000 | WIRE ASSY LOAD SENSOR         |
| 9        | 1    | 800657000 | WIRE 1C BLACK                 |
| 10       | 2    | 000300000 | TERMINAL RING RB 14-10        |



## ***HOSE REEL KIT***

***P/N: 407011000***




HOSES NOT SHOWN



## ***HOSE REEL KIT***

### ***P/N: 407011000***



| ITEM NO. | QTY. | PART NO.  | DESCRIPTION                                |
|----------|------|-----------|--------------------------------------------|
| 2        | 1    | 407305000 | HOSE REEL MTG BRKT                         |
| 3        | 2    | 350048000 | HOSE CLAMP ASSY                            |
| 4        | 1    | 368202    | HOSE REEL GUIDE ASSY                       |
| 5        | 1    | 368992    | HOSE REEL                                  |
| 6        | 2    | 008701    | SCW HX 3/8 UNC X 7/8 GR5                   |
| 7        | 2    | 021100    | WASHER SPLK 3/8                            |
| 8        | 2    | 330372    | NUT HEX 3/8-16 UNC                         |
| 9        | 2    | 812035231 | HOSE ASSY -5 JIC(F)/-6 JIC(F) X 231 LG     |
| 10       | 4    | 812036185 | HOSE ASSY -5 JIC(F) 90 ELL/-6 JIC(F) X 185 |



***NOTES***



P.O. Box 580697 \* Tulsa, OK 74158-0697  
4707 N. Mingo Rd. \* Phone (918) 836-0463

## LIMITED WARRANTY 2 YEAR PARTS AND LABOR

Auto Crane will warranty to the consumer for a period of (2) years parts and labor from the date of purchase. Each new Auto Crane unit they sell will be free under normal use and service from defects in material and workmanship. Date of purchase will be honored as the date indicated on the Bill of Sale, which must accompany the Warranty Registration and be on file with Auto Crane. Absent a valid Warranty Registration and appropriate documentation, the original date of manufacture, as indicated by the serial number on the product, will be used to determine the effective date of the 2 year warranty.

The obligation of Auto Crane under this warranty is limited to the replacement or repair of parts that appear to the manufacturer after review and/or inspection to be defective and paid flat rate labor for replacing defective parts. This warranty does not obligate Auto Crane to bear the travel time charges in connection with the replacement or repair of defective parts. Responsibility for customer's claims arising from misapplication, abuse, misuse or alteration of equipment or parts lies with the distributor or user and no warranty obligation is assumed in these circumstances by Auto Crane.

Auto Crane will in no event be liable for any consequential damages or contingent liabilities arising out of the failure of any Auto Crane Product or parts to operate properly.

Auto Crane makes no warranty in respect to component accessories, it being subject to the warranties of their respective manufacturers.

If field service, at the request of the distributor, is rendered and fault is found not to be with Auto Crane's product, the distributor shall pay the time and expense of the field representative.

Claims for service labor or other expenses that have incurred by the buyer without approval or authorization or Auto Crane will not be accepted.

When applying for warranty, claims may be handled by contacting your nearest authorized Auto Crane Distributor. All claims are to be filed in writing on an Auto Crane Warranty Claim Form.

**AUTO CRANE COMPANY IS UNDER NO OLIGATION TO EXTEND THIS WARRANTY TO ANY CUSTOMER FOR WHICH AN AUTO CRANE DELIVERY REPORT FORM HAS NOT BEEN COMPLETED AND ON FILE WITH AUTO CRANE COMPANY**





