




99903214: IM-16/117&18/129: PAGE 1: 20070510



Model 16/117
Model 18/129

Instruction Manual



NOTE

Read and understand this manual, the
IMT Operators Crane Safety Manual
and Safety Manual Supplement
before operating or maintaining your crane.

IOWA MOLD TOOLING CO., INC.

BOX 189, GARNER, IA 50438-0189

TEL: 641-923-3711

TECHNICAL SUPPORT FAX: 641-923-2424

Iowa Mold Tooling Co., Inc. is an Oshkosh Truck Corporation company.



TABLE OF CONTENTS

TABLE OF CONTENTS	2	8.0 TECHNICAL DATA	20
REVISIONS LIST	2	REFERENCE DIMENSIONS	20
1.0 INTRODUCTION	3	TECHNICAL DATA-16/117 (Domestic)	21
2.0 LOADER TERMINOLOGY	3	TECHNICAL DATA-16/117 (Metric)	22
3.0 CONTROL VALVES, SYMBOLS	4	TECHNICAL DATA-18/129 (Domestic)	23
4.0 OPERATING INSTRUCTIONS	5	TECHNICAL DATA-18/129 (Metric)	24
4.1 START UP	5	9. WORKING PRESSURE/PERFORMANCE	25
4.2 USING THE LOADER	8	WORKING PRESSURE-16/117 (Domestic units) ...	25
4.3 AFTER OPERATION	9	WORKING PRESSURE-16/117 (Metric units)	26
5. MAINTENANCE	9	WORKING PRESSURE-18/129 (Domestic units) ..	27
5.1 LUBRICATION INTERVALS	9	WORKING PRESSURE-18/129 (Metric units)	28
5.2 LUBRICATION CHART	10	10. HYDRAULIC SYSTEM	29
6.0 OPTIONS	10	10.1 DESCRIPTION	29
6.1 MANUAL EXTENSIONS	11	10.2 HYDRAULIC DIAGRAMS	29
7.0 LIFTING CAPACITY DIAGRAMS	11	STANDARD HYDRAULIC DIAGRAM	30
7.1 CAPACITY CHARTS	11	11. BLEEDING OF AIR	31
7.2 CAPACITY DIAGRAMS	11	12. REPAIR	31
CAPACITY CHART-16/117K2	12	13. SERVICE	31
CAPACITY CHART-16/117K3	13	13.1 FIRST SERVICE OVERHAUL	31
CAPACITY CHART-16/117K4	14	13.2 ANNUAL SERVICE OVERHAUL	32
CAPACITY CHART-16/117K5	15	13.3 RECOMMENDED HYDRAULIC OIL TYPES ..	32
CAPACITY CHART-18/129K2	16	13.4 RECOMMENDED LUBRICANTS	32
CAPACITY CHART-18/129K3	17		
CAPACITY CHART-18/129K4	18		
CAPACITY CHART-18/129K5	19		

REVISIONS LIST

DATE	LOCATION	DESCRIPTION OF CHANGE
-	-	-
20070228	COVER	UPDATED OWNERSHIP STATEMENT
20070510	12-19	ECN 9000 - UPDATED CAPACITY CHART ART FOR CONSISTENCY ACROSS MODELS



99903214: IM-16/117&18/129: PAGE 3: 20001117

1.0 INTRODUCTION

This instruction manual contains a description of the loader, instructions for operation, maintenance and repair of the loader. The instruction manual includes the following sections:

Sections 1 through 8 contain general instructions for the daily operation of the loader.

Sections 9 through 13 are primarily aimed at operators, installation and maintenance personnel and contain instructions for installation, adjustment, inspection, and maintenance.


It is important that you familiarize yourself with the contents of this manual before putting the loader into operation. The same applies to any operators and maintenance personnel of the loader. Also familiarize yourself with any other manuals or instructions which accompanied the loader.

It is also important to follow the recommended service schedules. These service overhauls aid in operational safety. They will also be of importance in the event of any warranty claims since IMT will attach great importance to whether these overhauls have been carried through by an authorized service center or not.

Due to continuous development and improvements, your loader model may have been changed slightly since the printing of this instruction manual.

2.0 LOADER TERMINOLOGY

The loader is designed as a truck mounted loader and therefore stationary mounting of the loader, mounting on agricultural tractors, special purpose vehicles and the like may only be performed according to specific agreement with IMT.



- | | |
|--|--------------------------|
| 1. Suspension traverse | 11. Mast/Column |
| 2. Control valve, loader | 12. Link arm, Inner boom |
| 3. Outrigger arm/Stabilizer beam | 13. Hinge pin |
| 4. Outrigger/Stabilizer extension cylinder | 14. Inner/Main boom |
| 5. Outrigger/Stabilizer leg | 15. Outer/Jib cylinder |
| 6. Control valve, outrigger | 16. Outer/Jib pin |
| 7. Rotation/Slewing cylinder | 17. Link arm, outer/jib |
| 8. Planetary gear | 18. Outer boom/Jib |
| 9. Inner Boom cylinder | 19. Extension booms |
| 10. Base | 20. Extension cylinder |







99903214: IM-16/117&18/129: PAGE 4: 20001117

3.0 CONTROL VALVES, SYMBOLS

Each control valve is labeled showing the functions of that particular valve.

Control levers should always be operated steadily and smoothly to avoid unnecessary strain on the loader.





4.0 OPERATING INSTRUCTIONS

4.1 START UP

WARNING

Prior to operation, read and understand the IMT Operators Crane Safety manual and any other safety manuals which accompanied the loader.

Before start up the operator must make sure that loader operation does not entail any unnecessary risk. Special attention must be paid to the following factors:

1. The ground must be sufficiently firm to accept the pressure from the outrigger legs. In case of heavy lifts we recommend the use of steel plates under the outrigger foot plates.
2. The ground must not be slippery (i.e., covered with ice, sand, etc.). After the driver has applied the parking brake, the truck must be able to accept the horizontal forces from the loader without skidding or moving.
3. The truck must be parked in such a manner that the operator has a complete and unobstructed view of the field of operation.
4. The operator must make sure that there are no electric wires or any other obstacles within the working radius of the loader.
5. The operator must inform any unauthorized persons that entry into the working area is not permitted.



DANGER


ELECTROCUTION HAZARD
THIS CRANE IS NOT INSULATED
DEATH OR SERIOUS INJURY
WILL RESULT FROM CONTACT
OR INADEQUATE CLEARANCE

Maintain safe clearance from electrical lines.
Allow for boom, electrical line, and loadline swaying.

This crane does not provide protection from contact
with or proximity to an electrically charged conductor.

Maintain a clearance of at least 10 feet between
any part of the crane, loadline or load and any electrical
line carrying up to 50,000 volts (50 kV). **If electrical
line voltage is unknown, assume maximum voltage
and maintain a clearance of at least 45 feet.**

NOMINAL VOLTAGE, kV (Phase to Phase)	MINIMUM REQUIRED DISTANCE
to 50	10 feet
Over 50 to 200	15 feet
Over 200 to 350	20 feet
Over 350 to 500	25 feet
Over 500 to 750	35 feet
Over 750 to 1000	45 feet



70392813



99903214: IM-16/117&18/129: PAGE 6: 20001117

General Rules:

For all work in proximity to power supply plants or overhead wires, the following general rules apply:

1. Caution must be exercised in the planning, instruction for, and execution of such work to prevent any risk or danger to persons, equipment or goods.
2. Any power supply plant, installation or wire must be considered live until the responsible power supply authority has provided a declaration that the opposite is true.
3. Any directions or guidelines from the responsible power supply authorities or public bodies must be strictly observed.

Any person or company directly responsible for the implementation of work in the proximity of overhead wires or electric power stations must make sure that all personnel involved in the execution of such work is familiar with any laws, rules or safety regulations, national as well as local, governing such work in the relevant country, territory or zone.

Not until the operator has checked the above may loader operation start.

1. Switch the change-over valve, if any, to "loader"
2. Engage the PTO at low revolutions. The engine revolution speed is regulated by means of the hand accelerator to ensure that the oil flow from the hydraulic pump corresponds to the recommended pump flow for the loader. When starting up in the cold, the oil should circulate for a few minutes before operation starts.
3. Apply the vehicle parking brake.
4. Starting up:
 - a. Pull out the emergency stop button - remember both sides of the loader, if necessary.
 - b. Push the green button once, the "RUN" diode is lit and the safety system is activated.

Stabilizer function:


- c. Push the yellow button and the "FUNC" and "F5" diodes are lit. After 10 seconds the diodes are turned off, but the stabilizer function remains activated. Now the stabilizer function is activated and items 5 through 7 below must be carried out.

Loader function:

- d. Either: Activate one of the control levers of the loader's control valve
or: Push the yellow button twice; "FUNC" is lit and "F5" is turned off.

All loader functions are now activated - carry out item 8.

5. Release the stabilizer lock and extend the stabilizer beam completely, and **lock it again**. If the stability of the vehicle and the loader is based on the outrigger legs being fully deployed. The loader should only be used when the outriggers are fully deployed. The operator must make sure that the vehicle has sufficient stability in the area in front of the outriggers (over the cab). The outriggers should be lowered just enough to raise the truck chassis a little in its suspensions. The tires must still have full contact with the ground.




During loading of the truck, the operator must raise the outrigger legs periodically to ensure that the truck and not the outriggers carry the weight. The outrigger legs are not designed to support this excessive load.

6. The vehicle must be positioned as close to horizontal as possible. Therefore, the driver should place the truck in as close a horizontal position as possible by means of the outrigger legs before operating the loader.
7. If the ground is not firm enough to take up the pressure of the outrigger legs, a plate, preferably steel, must be placed under the foot plates.



99903214: IM-16/117&18/129: PAGE 7: 20001117

8.1. The unfolding of the loader takes place as described below:



I. Extend outrigger beams fully.

II. Lower the outrigger legs according to items 5, 6 and 7 above.

III. The outer (jib) **must** be raised (the “outer/jib down” movement of the lever), so that the outer boom (jib) is released from the bracket.


IV. Raise the inner (main) boom and thereby release it from the bracket. Raise the inner (main) boom somewhat above horizontal, so that the outer boom can be moved freely downwards.

V. Raise the outer (jib) until it is free from the base.

NOTE

In the case of loaders equipped with stop bracket on the outer (jib), extend the extension booms a little until the stop bracket is released.

Stop bracket





99903214: IM-16/117&18/129: PAGE 8: 20001117

4.2 USING THE LOADER

After unfolding the loader, work may begin.

The lifting capacity of the loader is shown on the Capacity Chart on the loader and in this instruction manual. The capacity limits indicated must never be exceeded.

The loader is designed to lift loads vertically and therefore diagonal stresses must be avoided. Consequently the dragging of loads across the ground using the extension cylinders or the rotation system must be avoided. These functions should only be activated once the load is free of the ground.

When mounting a grapple, the total weight (grapple, rotator, and contents) must not exceed the lifting capacity of the loader at maximum reach. The grapple may be used to move soil only. It must not be used to excavate earth. Damage caused by improper operation of the loader will not be covered by the Warranty.

If the load is extended so far that the lifting capacity is exceeded, the load moment increasing movements will be stopped. See the RCL Safety System Instruction Manual.

WARNING

Never stand under the booms when the loader is working.

NOTES

Position the truck as closely to the load as possible to lift the load on the shortest possible boom.

The rotation system should be operated with care, especially when the inner boom is at an acute angle to the outer boom.

The outriggers may not be activated when the loader is working.

Never drive off with a suspended load.



4.3 AFTER OPERATION

The loader is folded up by reversing the procedure described in item 8, chapter 4.1 "Starting up". If the boom is parked on the truck platform it must be properly secured to prevent the boom from swinging out during transport. Also, the operator must check that the total height does not exceed 157" (4000mm).

If the loader is equipped with swing-up outrigger legs, they must also be secured in position before driving off.


Before the vehicle is started, the PTO must be disengaged; i.e. the pump must be turned off.

5. MAINTENANCE

Careful maintenance of the loader is the best way to ensure reliable loader operation.

At regular intervals, every day or every week, depending on frequency of loader application, you should check the following:

1. The oil level in tank and rotation system. Oil must be visible in the oil level glass of the tank when the loader is folded. If the loader is equipped with a planetary gear, check its oil level.
2. Any defects, damage or leaks should be repaired at an authorized service center as soon as discovered.
3. Loader to truck mounting hardware.
4. Slide blocks and bushings reduce friction and therefore they are naturally subject to wear. Slide blocks should be replaced when slack is detected in the boom system. Bushings should be replaced before the metal components physically touch each other.
5. Check all hoses for defects and kinks.
6. Check that hooks, straps and safety latches are in good working order.
7. Check all lock pins and bolts for wear.



Service overhauls should be undertaken according to Section 13. In case of any warranty claims later, great importance will be attached to observance of these service overhauls.

5.1 LUBRICATION INTERVALS

Pinion of mast/Planetary gear (if any): after 50 hours of operation/1 month (whichever occurs first)

Base bearings: after 20 hours of operation/1 week (whichever occurs first)

Extension system/Slide blocks: after 50 hours of operation/1 month (whichever occurs first)

Guide rail on extension cylinders: after 50 hours of operation/1 month (whichever occurs first)

Pin connections/Bolts: after 50 hours of operation/1 month (whichever occurs first)


Outrigger beams: as required

Control valves and rod connections (Oil spray): as required

The loader should be lubricated according to the lubrication chart below. Also see "Recommended Lubricants".



5.2 LUBRICATION CHART



The rotation system should be activated and the loader swung from stop to stop several times within the entire rotation area at the same time as the bearings in the base are lubricated.

Hydraulic oil and lubrication grease are chosen according to the table in Section 13.

The telescopic extensions and planetary gear are lubricated with a special grease (Statoil Grease Way CaH or Castrol ALV).

CAUTION

If the loader is not folded after use, make sure that all cylinders are completely retracted at least once a day. The protective oil coating on the piston rods is thus maintained, preventing corrosion from occurring on the chromium surface.

6.0 OPTIONS

Various options are available with the loader:

- Fly-Jib
- Manual extensions
- Winch
- Pallet fork
- Remote control
- Radio remote control

Some loaders may, as standard, be equipped with options such as manual extensions, winch and Fly-Jib. For those loaders you will, apart from the descriptions below, also find technical data and pressure setting diagram, as well as lifting capacity diagrams for the Fly-Jib in this manual.

You should always consult your authorized dealer before mounting any optional equipment. This also applies to equipment already in your possession.

CAUTION

Welding onto or drilling into the structural components of the loader will automatically invalidate any liability on the part of IMT.



99903214: IM-16/117&18/129: PAGE 11: 20001117

6.1 MANUAL EXTENSIONS

When working with manual extensions, please note:

The load limits indicated for manual extensions must never be exceeded.

Great care must be taken if the rotation system is to be activated during work with manual extensions.

If the loader is fitted with manual extensions or other options, the lifting capacity of the loader must be reduced by the weight of the options.

Always check that lock bolts are fitted correctly with a pin.

If the loader is fitted with several extensions and a certain lifting job requires the use of one extension only, use the extension with the largest box profile.

WARNING

Only pull out the manual extensions when the outer (jib) is as close to horizontal as possible. If the outer (jib) is pointed downwards when the lock is removed, the extensions will drop out at uncontrollable speed. This may damage the stop at the risk of resulting in personal injury.

The load must be extended from the stop; i.e. the extension lock pins must always remain in place.

7.0 LIFTING CAPACITY DIAGRAMS

7.1 CAPACITY CHARTS

From the factory, the loader is equipped with lifting capacity labels for the loader as well as for the options (manual extensions, Fly-Jib), if any. These labels must, just like any other labels on the loader, be intact and legible. If the label has been damaged or removed, you can order a new label from IMT. Use the part number used on the label or consult the parts manual, decal kit.

7.2 CAPACITY DIAGRAMS

As a supplement to the loader's lifting capacity labels, the following pages contain load and lifting capacities of the different K-versions in standard applications, i.e. special applications and customized labels and options are not taken into consideration. In these cases we refer to the supplementary documentation delivered and/or the lifting capacity labels on the loader.


WARNING

The lifting capacity limits indicated must never be exceeded.



99903214: IM-16/117&18/129: PAGE 12: 20070510

CAPACITY CHART-16/117K2





99903214: IM-16/117&18/129: PAGE 13: 20070510


CAPACITY CHART-16/117K3

IMT
MATERIAL HANDLING SYSTEMS

IOWA MOLD TOOLING CO., INC.
BOX 189 • GARNER • IA • 50438 • 641-923-3711

Model 16/117K3

- Working loads will be limited to those shown. Deduct the weight of load handling devices.
- Before lift is made, stability must be checked per SAE J765A.



70395339



99903214: IM-16/117&18/129: PAGE 14: 20070510


CAPACITY CHART-16/117K4

IMT
MATERIAL HANDLING SYSTEMS

IOWA MOLD TOOLING CO., INC.
BOX 189 • GARNER • IA • 50438 • 641-923-3711

Model 16/117K4

- Working loads will be limited to those shown. Deduct the weight of load handling devices.
- Before lift is made, stability must be checked per SAE J765A.



70395340




CAPACITY CHART-16/117K5

IMT
MATERIAL HANDLING SYSTEMS

IOWA MOLD TOOLING CO., INC.
BOX 189 • GARNER • IA • 50438 • 641-923-3711

Model 16/117K5

- Working loads will be limited to those shown. Deduct the weight of load handling devices.
- Before lift is made, stability must be checked per SAE J765A.



70395341



99903214: IM-16/117&18/129: PAGE 16: 20070510


CAPACITY CHART-18/129K2

IMT
MATERIAL HANDLING SYSTEMS

IOWA MOLD TOOLING CO., INC.
BOX 189 • GARNER • IA • 50438 • 641-923-3711

Model 18/129K2

- Working loads will be limited to those shown. Deduct the weight of load handling devices.
- Before lift is made, stability must be checked per SAE J765A.



70395344



99903214: IM-16/117&18/129: PAGE 17: 20070510


CAPACITY CHART-18/129K3

IMT
MATERIAL HANDLING SYSTEMS

IOWA MOLD TOOLING CO., INC.
BOX 189 • GARNER • IA • 50438 • 641-923-3711

Model 18/129K3

- Working loads will be limited to those shown. Deduct the weight of load handling devices.
- Before lift is made, stability must be checked per SAE J765A.




70395345



99903214: IM-16/117&18/129: PAGE 18: 20070510

CAPACITY CHART-18/129K4





CAPACITY CHART-18/129K5


IMT

MATERIAL HANDLING SYSTEMS

IOWA MOLD TOOLING CO., INC.
BOX 189 • GARNER • IA • 50438 • 641-923-3711

Model 18/129K5

- Working loads will be limited to those shown. Deduct the weight of load handling devices.
- Before lift is made, stability must be checked per SAE J765A.






8.0 TECHNICAL DATA

The following pages contain tables with technical data on loader and Fly-Jib respectively, if a Fly-Jib is available as standard.

As standard the 16/117 K3 loader designation describes a loader with a 16 ton-meter/117000 foot-pound load moment and utilizes 3 hydraulic extensions. The 18/129 K3 loader designation describes a loader with a 18 ton-meter/129000 foot-pound load moment and utilizes 3 hydraulic extensions.

REFERENCE DIMENSIONS



**TECHNICAL DATA-16/117 (Domestic)**

Performance	Unit	2 hyd ext	3 hyd ext	4 hyd ext	5 hyd ext
Crane Rating*	ft-lbs	112115	109950	105600	103430
Max Horiz Reach	ft & in	28'-3"	35'-1"	42'-4"	49'-7"
Max Vert Reach	ft & in	36'-0"	42'-10"	50'-2"	57'-5"
Max. Capacity	lbs	14000	13890	13780	13560
Max Cap@Max Reach	lbs	3880	2830	2150	1590
Crane Weight**	lbs	4025	4355	4630	4860
Hook Approach					
Vertical	ft & in	9'-3"	9'-0"	8'-9"	8'-4"
Horizontal	ft & in	2'-6"	2'-8"	2'-11"	3'-3"
Center of Gravity (Stored)					
Vertical	inches	31.0"	32.0"	33.0"	33.0"
Horiz (C/L Rot-Bridge)	inches	2.0"	3.0"	3.5"	4.0"
Outrigger Pad Diameter	inches	9.0"	9.0"	9.0"	9.0"
Crane Storage Height	ft & in	7'-6"	7'-6"	7'-6"	7'-6"
Mounting Space***	inches	33.0"	33.0"	33.0"	35.4"
Rotation Torque	ft-lbs	17360	17360	17360	17360
Rotation Angle	degrees	410	410	410	410
Optimum Pump Capacity	gpm (US)	13	13	13	13
System Pressure	psi	3915	3915	3915	3915
Oil Reservoir Capacity	gal	22.5	22.5	22.5	22.5
Outrigger Extension Span					
Std-mnl out/hyd dn	ft & in	16'-9"	16'-9"	16'-9"	16'-9"
Weight	lbs	550	550	550	550
Opt-hyd out/hyd dn	ft & in	21'-1"	21'-1"	21'-1"	21'-1"
Weight	lbs	720	720	720	720

Minimum Chassis Specifications

Front Axle Rating (GAWR)	lbs	12000	12000	12000	12000
Rear Axle Rating (GAWR)	lbs	21000	21000	21000	21000
RBM	in-lb	1,680,000	1,680,000	1,680,000	1,680,000

Measures

Height above chassis					
when folded	in	87.4	87.4	87.4	87.4
Width when folded	in	98.4	98.4	98.4	98.4
Length, without					
extra valves	in	32.7	32.7	32.7	35.4
Length, with					
extra valves	in	37.2	37.2	37.2	40.2

* Maximum Crane Rating (ft-lbs) is defined as that rated load (lbs) which when multiplied by its respective distance (ft) from centerline of rotation gives the greatest ft-lb value.

** Crane weight excluding outriggers.

*** Additional mounting space of 11" will be required to provide crane rotational clearance.

**TECHNICAL DATA-16/117 (Metric)**

Performance	Unit	2 hyd ext	3 hyd ext	4 hyd ext	5 hyd ext
Crane Rating*	ton-m	15.5	15.2	14.6	14.3
Max Horiz Reach	m	8.6	10.7	12.9	15.1
Max Vert Reach	m	11.0	13.1	15.3	17.5
Max. Capacity	kgs	6350	6300	6250	6150
Max Cap@Max Reach	kgs	1760	1285	975	720
Crane Weight	kgs	1825	1975	2100	2205
Hook Approach					
Vertical	m	2.8	2.8	2.7	2.6
Horizontal	m	0.76	0.82	0.89	1.00
Center of Gravity (Stored)					
Vertical	mm	790	810	830	840
Horiz (C/L Rot-Bridge)	mm	40	70	90	105
Outrigger Pad Diameter	mm	220	220	220	220
Crane Storage Height	m	2.3	2.3	2.3	2.3
Mounting Space	mm	830	830	830	900
Rotation Torque	ton-m	2.4	2.4	2.4	2.4
Rotation Angle	degrees	410	410	410	410
Optimum Pump Capacity	liters/min	49	49	49	49
System Pressure	bar	270	270	270	270
Oil Reservoir Capacity	liters	85	85	85	85
Outrigger Extension Span					
Std-mnl out/hyd dn	m	5.1	5.1	5.1	5.1
Weight	kgs	250	250	250	250
Opt-hyd out/hyd dn	m	6.4	6.4	6.4	6.4
Weight	kgs	325	325	325	325

Minimum Chassis Specifications

Front Axle Rating (GAWR)	kgs	5443	5443	5443	5443
Rear Axle Rating (GAWR)	kgs	9525	9525	9525	9525
RBM	kg-m	19362	19362	19362	19362

Measures

Height above chassis					
when folded	mm	2272	2272	2272	2272
Width when folded					
	mm	2500	2500	2500	2500
Length, without					
extra valves	mm	830	830	830	900
Length, with					
extra valves	mm	945	945	945	1020

* Maximum Crane Rating (ton-m) is defined as that rated load (ton) which when multiplied by its respective distance (m) from centerline of rotation gives the greatest ton-m value.

** Crane weight excluding outriggers.

*** Additional mounting space of 280mm will be required to provide crane rotational clearance.

**TECHNICAL DATA-18/129 (Domestic)**

Performance	Unit	2 hyd ext	3 hyd ext	4 hyd ext	5 hyd ext
Crane Rating*	ft-lbs	124410	122240	117175	115005
Max Horiz Reach	ft & in	28'-3"	35'-1"	42'-4"	49'-7"
Max Vert Reach	ft & in	36'-0"	42'-10"	50'-2"	57'-5"
Max. Capacity	lbs	15220	15100	14995	14770
Max Cap@Max Reach	lbs	4320	3195	2425	1830
Crane Weight**	lbs	4055	4385	4660	4995
Hook Approach					
Vertical	ft & in	9'-3"	9'-0"	8'-9"	8'-4"
Horizontal	ft & in	2'-6"	2'-8"	2'-11"	3'-3"
Center of Gravity (Stored)					
Vertical	inches	31.0"	32.0"	33.0"	33.0"
Horiz (C/L Rot-Bridge)	inches	2.0"	3.0"	3.5"	4.0"
Outrigger Pad Diameter	inches	9.0"	9.0"	9.0"	9.0"
Crane Storage Height	ft & in	7'-6"	7'-6"	7'-6"	7'-6"
Mounting Space***	inches	33.0"	33.0"	33.0"	35.4"
Rotation Torque	ft-lbs	17360	17360	17360	17360
Rotation Angle	degrees	410	410	410	410
Optimum Pump Capacity	gpm (US)	13	13	13	13
System Pressure	psi	4275	4275	4275	4275
Oil Reservoir Capacity	gal	22.5	22.5	22.5	22.5
Outrigger Extension Span					
Std-mnl out/hyd dn	ft & in	16'-9"	16'-9"	16'-9"	16'-9"
Weight	lbs	550	550	550	550
Opt-hyd out/hyd dn	ft & in	21'-1"	21'-1"	21'-1"	21'-1"
Weight	lbs	720	720	720	720

Minimum Chassis Specifications

Front Axle Rating (GAWR)	lbs	12000	12000	12000	12000
Rear Axle Rating (GAWR)	lbs	21000	21000	21000	21000
RBM	in-lb	1,850,000	1,850,000	1,850,000	1,850,000

Measures

Height above chassis					
when folded	in	87.4	87.4	87.4	87.4
Width when folded	in	98.4	98.4	98.4	98.4
Length, without					
extra valves	in	32.7	32.7	32.7	35.4
Length, with					
extra valves	in	37.2	37.2	37.2	40.2

* Maximum Crane Rating (ft-lbs) is defined as that rated load (lbs) which when multiplied by its respective distance (ft) from centerline of rotation gives the greatest ft-lb value.

** Crane weight excluding outriggers.

*** Additional mounting space of 11" will be required to provide crane rotational clearance.

**TECHNICAL DATA-18/129 (Metric)**

Performance	Unit	2 hyd ext	3 hyd ext	4 hyd ext	5 hyd ext
Crane Rating*	ton-m	17.2	16.9	16.2	15.9
Max Horiz Reach	m	8.6	10.7	12.9	15.1
Max Vert Reach	m	11.0	13.1	15.3	17.5
Max. Capacity	kgs	6900	6850	6800	6700
Max Cap@Max Reach	kgs	1960	1450	1100	830
Crane Weight	kgs	1840	1990	2115	2220
Hook Approach					
Vertical	m	2.8	2.8	2.7	2.6
Horizontal	m	0.76	0.82	0.89	1.00
Center of Gravity (Stored)					
Vertical	mm	790	810	830	840
Horiz (C/L Rot-Bridge)	mm	40	70	90	105
Outrigger Pad Diameter	mm	220	220	220	220
Crane Storage Height	m	2.3	2.3	2.3	2.3
Mounting Space	mm	830	830	830	900
Rotation Torque	ton-m	2.4	2.4	2.4	2.4
Rotation Angle	degrees	410	410	410	410
Optimum Pump Capacity	liters/min	49	49	49	49
System Pressure	bar	295	295	295	295
Oil Reservoir Capacity	liters	85	85	85	85
Outrigger Extension Span					
Std-mnl out/hyd dn	m	5.1	5.1	5.1	5.1
Weight	kgs	250	250	250	250
Opt-hyd out/hyd dn	m	6.4	6.4	6.4	6.4
Weight	kgs	325	325	325	325

Minimum Chassis Specifications

Front Axle Rating (GAWR)	kgs	5443	5443	5443	5443
Rear Axle Rating (GAWR)	kgs	9525	9525	9525	9525
RBM	kg-m	21500	21500	21500	21500

Measures

Height above chassis					
when folded	mm	2272	2272	2272	2272
Width when folded	mm	2500	2500	2500	2500
Length, without					
extra valves	mm	830	830	830	900
Length, with					
extra valves	mm	945	945	945	1020

* Maximum Crane Rating (ton-m) is defined as that rated load (ton) which when multiplied by its respective distance (m) from centerline of rotation gives the greatest ton-m value.

** Crane weight excluding outriggers.

*** Additional mounting space of 280mm will be required to provide crane rotational clearance.



9. WORKING PRESSURE/PERFORMANCE

The working pressure should be set with a pressure gauge and the limits stated in the tables below must be kept.


The working pressure must be checked during the annual service overhaul and in the event of any major repairs.

The procedure for checking and setting of load-holding valves is described in Service Information. All adjustable valves must be resealed after pressure setting adjustment.

Please note that any warranty obligations on the part of IMT will be invalidated if the conditions stated in this manual are not complied with.

WORKING PRESSURE-16/117 (Domestic units)

Basic position
during test and
adjustment of
valves



Working pressure on main-relief valve & port-relief valves

Function	Port	Unit	16/117
Main-relief valve		psi	3915
Rotation system	right	A-port	2540
	left	B-port	2540
Inner boom cylinder	down	A-port	1015
	up	B-port	P
Outer boom cylinder	up	A-port	4350
	down	B-port	2175
Extension cylinders	extend	A-port	P
	retract	B-port	P
Rotator		A-port	2900
		B-port	2900
Grapple		A-port	3625
		B-port	3625
Separate outrigger valve			1815

Opening pressure on load holding valves

Inner boom cylinder			5075
Outer boom cylinder			4495
Extension cyl	extend	A-port	3045
Extension cyl	retract	B-port	6235
External relief valve			4280

Pressure setting for load moment limitation

LMB	3770
-----	------

Max. Pump performance


Pump performance	gpm	13.21
------------------	-----	-------



99903214: IM-16/117&18/129: PAGE 26: 20001117

WORKING PRESSURE-16/117 (Metric units)

Basic position
during test and
adjustment of
valves

**Working pressure on main-relief valve & port-relief valves**

Function	Port	Unit	16/117
Main-relief valve		MPa	27.0
Rotation system	right	A-port	17.5
	left	B-port	17.5
Inner boom cylinder	down	A-port	7.0
	up	B-port	P
Outer boom cylinder	up	A-port	30.0
	down	B-port	15.0
Extension cylinders	extend	A-port	P
	retract	B-port	P
Rotator		A-port	20.0
		B-port	20.0
Grapple		A-port	25.0
		B-port	25.0
Separate outrigger valve			12.5

Opening pressure on load holding valves

Inner boom cylinder			35.0
Outer boom cylinder			31.0
Extension cyl	extend	A-port	43.0
Extension cyl	retract	B-port	21.0
External relief valve			29.5

Pressure setting for load moment limitation

LMB	26.0
-----	------

Max. Pump performance

Pump performance	l/min	50.0
------------------	-------	------


1 MPa = 10 bar



99903214: IM-16/117&18/129: PAGE 27: 20001117

WORKING PRESSURE-18/129 (Domestic units)

Basic position
during test and
adjustment of
valves

**Working pressure on main-relief valve & port-relief valves**

Function		Port	Unit	18/129
Main-relief valve			psi	4280
Rotation system	right	A-port		2540
	left	B-port		2540
Inner boom cylinder	down	A-port		1015
	up	B-port		P
Outer boom cylinder	up	A-port		4350
	down	B-port		2175
Extension cylinders	extend	A-port		P
	retract	B-port		P
Rotator		A-port		2900
		B-port		2900
Grapple		A-port		3625
		B-port		3625
Separate outrigger valve				1815

Opening pressure on load holding valves

Inner boom cylinder			5075
Outer boom cylinder			4785
Extension cyl	extend	A-port	3045
Extension cyl	retract	B-port	6235
External relief valve			4640

Pressure setting for load moment limitation

LMB	4135
HDL	3770

Max. Pump performance


Pump performance	gpm	13.21
------------------	-----	-------



99903214: IM-16/117&18/129: PAGE 28: 20001117

WORKING PRESSURE-18/129 (Metric units)

Basic position
during test and
adjustment of
valves

**Working pressure on main-relief valve & port-relief valves**

Function		Port	Unit	18/129
Main-relief valve			MPa	29.5
Rotation system	right	A-port		17.5
	left	B-port		17.5
Inner boom cylinder	down	A-port		7.0
	up	B-port		P
Outer boom cylinder	up	A-port		30.0
	down	B-port		15.0
Extension cylinders	extend	A-port		P
	retract	B-port		P
Rotator		A-port		20.0
		B-port		20.0
Grapple		A-port		25.0
		B-port		25.0
Separate outrigger valve				12.5

Opening pressure on load holding valves

Inner boom cylinder			35.0
Outer boom cylinder			33.0
Extension cyl	extend	A-port	21.0
Extension cyl	retract	B-port	43.0
External relief valve			32.0

Pressure setting for load moment limitation

LMB	28.5
HDL	26.0

Max. Pump performance

Pump performance	l/min	50.0
------------------	-------	------

1 MPa = 10 bar



10. HYDRAULIC SYSTEM

10.1 DESCRIPTION

The valve block of the loader is of the “stack” type, i.e., it is made up of a number of separate control valves. This ensures great flexibility and low maintenance costs.

A main relief valve is fitted in the inlet section of the valve block to ensure that the oil pressure in the pump line does not exceed the permissible limit. This valve is adjustable and must always remain sealed.

Port relief valves are mounted at the ports of the individual control valves to limit the pressure in the individual circuits. Normally the port relief valves will be pre-set and not adjustable.

The inner, outer, and extension cylinders are mounted with load holding valves with the following functions:

1. Protection of cylinders against excessive pressure.
2. Checking of the lowering speed of the boom.
3. Maintain the boom in position during operations where a fixed boom position is required.
4. To lock the boom and maintain the load in position in case of hose or pipe rupture.

The outrigger cylinders are equipped with a piloted check valve that locks the cylinder in case of damage to the hydraulic system.

CAUTION

The main relief valve, the load holding valves, the dump valve and the external relief valve are sealed. If these seals are broken or removed the warranty will automatically be invalidated. Therefore, it is in your own interest to have the seals checked from time to time and to make sure that they are replaced by an authorized IMT service center should they be damaged.

Any modification or alteration to the hydraulic system must be in accordance to specific agreement with IMT and such alterations should always take place at an IMT service center.

10.2 HYDRAULIC DIAGRAMS


Hydraulic diagrams are a great help when troubleshooting and repairing the hydraulic system.

The following page contains the hydraulic diagram for the loader in standard application, as well as for options, if any.

There may be changes in design of the hydraulic system when applied to special and/or customized loaders. In these cases refer to the supplementary documentation.



STANDARD HYDRAULIC DIAGRAM





99903214: IM-16/117&18/129: PAGE 31: 20001117

11. BLEEDING OF AIR

If air has entered the hydraulic system, the loader is bled as follows:

1. Raise and lower each outrigger leg twice.
2. Extend and retract the inner boom cylinder twice.
3. Extend and retract the outer cylinder twice with the inner boom pointing downward, and twice with the inner boom pointed upward.
4. Extend and retract the extension cylinder twice with the outer boom pointed almost vertically upward, and twice with the outer boom pointed almost vertically downward.

12. REPAIR

If defects, damage or leaks are found, repair them immediately. Always have your repairs performed by an authorized IMT service center. Repairs to the hydraulic system must be made only at an authorized service center.

When ordering parts for your loader, please state:

- Loader model
- Loader serial number (found on serial number placard on loader)

13. SERVICE

13.1 FIRST SERVICE OVERHAUL

We recommend that the first service overhaul takes place at an authorized IMT service center after the first 20 hours of service or after one month of loader use at the latest. This service check is rather important since the loader will be properly run in after 20 hours of use.

The first service overhaul should include the following:

1. Change of return filter element and high pressure filter cartridge, if any.
2. The oil level in tank and rotation system. Oil must be visible between maximum and minimum lubrication on the oil level rod, when the loader is in the folded position. The oil level in the slewing system should also be visible in the inspection tube.
3. Overall lubrication according to the lubrication chart in this manual.
4. Leak check and tightening of fittings, if required.
5. Checking of working pressure and lead seals. The correct working pressures are stated in relevant Technical Information sheets.
6. Test of all functions under load.
7. Checking and, if required, tightening of mounting bolts and pin connections.
8. Checking of all lock bolts and pins.



13.2 ANNUAL SERVICE OVERHAUL

Once a year the loader should be given a main service overhaul at an authorized IMT service center. The loader should be thoroughly checked and special attention should be paid to the following items:

1. Change of hydraulic oil in tank and rotation system, if any.
2. Change of return filter element and high pressure filter cartridge.
3. Cleaning or replacement of air filter.
4. Checking of working pressure and valve lead seals.
5. Idling pressure check.
6. Test of all functions under load.
7. Checking of slide blocks and bearing bushings for wear and, if required, replacement of the same.
8. Check of hydraulic hoses.
9. Leak check and tightening of all connections.
10. Check of pump and transmission.
11. Check of loader base to chassis mounting hardware.
12. Checking of all bolt connections and tightening, if required.
13. Overall checking of loader structure for damage. Any damage found should be repaired immediately.
14. Checking of all bolts and lock plates.

13.3 RECOMMENDED HYDRAULIC OIL TYPES

Oil Brand	Oil Type	Low Temp Oil Type
BP	Bartran HV 32	Bartran HV 22
Castrol	Hyspin AWS 32	Hyspin AWH 32
ESSO	Nuto H 32	Univis N 22
Kuwait petroleum Q8	Harmony 32 AW	Hydraulic L 32
Mobil	DTE 13	DTE 11
Shell	Tellus S 32	Tellus T 32
Statoil	Hydra Way HM 32	Hydra Way HV 22
Texaco	Rando HD 32	Rando HDZ 32

13.4 RECOMMENDED LUBRICANTS

Grease Brand	Grease for Bearings
BP	Energ grease L52
Castrol	LM Grease
ESSO	MP Grease I Beacon EP 2
Mobil	Mobilux EP 2 or Mobilgrease HP
Shell	Retinox MS
Statoil	Uni Way EP 2
Texaco	Multifak All Purpose EP 2

Grease containing molybdenum disulphide must not be used.

Grease Brand	Grease for Telescopic Extensions
Statoil	Grease Way CaH 92
Castrol	ALV





99903214: IM-16/117&18/129: PAGE 34: 20001117

IOWA MOLD TOOLING CO., INC.

BOX 189, GARNER, IA 50438-0189

TEL: 641-923-3711

TECHNICAL SUPPORT FAX: 641-923-2424