




Ideal Crane Boom Rest

- ◆ Secure your crane while traveling
- ◆ Powder coated to match Liberator cranes
- ◆ Keyway design for positive locking with out marring finish
- ◆ Full size base plate to span utility compartment




800-622-6163

**RUGGED
and
DEPENDABLE**

www.idealcrane.com

IDEAL CRANE LLC - PO BOX 35249 - TULSA, OKLAHOMA 74153-0249

Boom Rest Dimensions



***NOTE:** Adjustable Boom Rest requires welding the telescopic sections together at the custom height. For this reason, adjustable Boom Rest is shipped prime painted.

Boom Rest Location

From center of rotation

